



SENTINEL



SurePoint Ag Systems



Read this Manual and keep it in the cab.

Other Resources

396-4953Y1 Manual for PumpRight System using Sentinel Rate Control

396-4954Y1 Manual for Tower System using Sentinel Rate Control

396-4608Y1 Gen3 LiquiShift Manual

396-4034Y1 PumpRight Pump Manual

[Sentinel support site](https://support.surefireag.com/products/346) <https://support.surefireag.com/products/346>

- Manuals
- ECU Software Update
- Videos
- Support Bulletins

System Summary (helpful for tech support)

System Purchased from: _____

Date Purchased: _____

S0 number from Sales Order: S0 _____

Using Sentinel for: ☐ Row Monitoring ☐ Rate Control ☐ Gen3 LiquiShift

Pump: ☐ Electric ☐ PR17 ☐ PR30 ☐ PR40 ☐ D250

Implement: _____

Metering Tube colors _____ & _____ ☐ 8' ☐ 5' ☐ Other

Implement Width _____ Rows _____ Spacing _____ Sections _____

Table Of Contents

Introduction

- Basic Steps to Install your Sentinel System 1
- Complete Fertilizer System Example Drawing 2-3

A

Introduction

Components - Liquid

- Parts and Fittings - Manifold feed- Isolated Feed 4-5

B

Components

Components - Wiring & Electrical

- Harness Overview / Layout..... 6-7
- Harness Drawings - 5021 - Row Monitoring 8-11
- Harness Drawings - 5022 - Rate Control /Row Monitoring..... 12-17
- Harness Drawings - 5023 - Gen3 LS / Rate Control / Row Monitoring 18-22
- Connector Pinouts - 5022 and 5023 23-24
- CAN Trunklines, Front ISO Extension..... 25-26

C

Components
Wiring & Elec.

Setup & Operation

- Getting Sentinel on VT 27-28
- Sentinel Icons 29
- Sentinel Startup Light Sequence..... 30

D

Setup &
Operation

Row Monitoring

- **Sentinel Row Monitoring Setup..... 31-46**
- Setup Overview 32-33
- Settings - Product - Device Setup 34
- Sections, Rows, Tolerance, Rates, Smoothing, LiquiShift Enable 35
- Implement, Speed , Hardware: Foot switch, Height switch, TC, IntelliSection .. 36
- Rate Setup, Smoothing, Flow Adjustment, 2 product setup..... 37
- Flow Module Addressing, ABCD or DCBA 38
- Customizing Scans and Alarms, Flow Module Diagnostics, Object Pool 39
- Row Detail Screen, Software Version, Auxiliary Settings 40
- **LiquiShift setup with Row Monitoring 41**
- Operating Row Monitoring, Customizable Toolbar, Totalizer Counters 42-43
- Row Monitoring Home Screen, Alarm Screen, Row Detail Screen..... 44
- Fine-Tuning Sentinel Row Monitoring 45

Rate Control

- **Sentinel Rate Control Setup with NO Row Monitoring..... 47-62**
- Setup Overview 48-49
- Settings - Product - Device Setup 50
- Sections, Rows, Tolerance, Rates, Smoothing, LiquiShift Enable 51
- Implement, Speed , Hardware: Foot switch, Height switch, Task Control 52
- Rate Setup, Smoothing, 2 product setup, Software, Aux Settings 53
- Rate Control Setup, Control Speed, Flow Cal, PWM Max and Min 54
- **LiquiShift setup with Rate Control..... 55**
- Nozzle Test (Simulated speed / rate test) 56
- Catch Test (Flowmeter Calibration)..... 57-58
- Customizable Toolbar, Totalizer Counters 59
- Manual operation, Setup and Diagnostic Tabs..... 60-61

Table Of Contents

• Sentinel Rate Control with Row Monitoring Setup	63-83
• Setup Overview.....	64-66
• Settings - Product - Device Setup	67
• Sections, Rows, Tolerance, Rates, Smoothing, LiquiShift Enable	68
• Implement, Speed , Hardware (Foot switch, Height switch), IntelliSection.....	69
• Rate Setup, Smoothing, Flow Adjustment, 2 product setup.....	70
• Flow Module Addressing, ABCD or DCBA	71
• Customizing Scans and Alarms, Flow Module Diagnostics, Next VT	72
• Rate Control Setup Tab, Control Speed, RPM Cal, Flow Cal, PWM Max/Min ..	73
• Software Version, Auxiliary Settings Screen	73
• LiquiShift Enable and LiquiShift Setpoints	74
• Row Detail Screen, Row Enable/Disable, Flow Adj for Row	75
• Customizable Toolbar, Totalizer Counters	76
• Rate Control & Row Monitoring Home Screen	77-78
• Manual Operation, Setup & Diagnostic Tabs.....	78-79
• Nozzle Test (Simulated speed / rate test).....	80
• Catch Test (Flowmeter Calibration).....	81-82
• Fine-Tuning Sentinel Row Flow Monitoring	83

D

Setup &
Operation

Troubleshooting

• Fine-Tuning Sentinel Row Flow Monitoring	83
• Sentinel Doesn't Show up on Display (VT).....	84
• Flow module addressing issues, Rows are Grey on Bar Graph.....	84
• Sentinel shows row reading too high or too low	85
• Sentinel Alarms too often	85
• As applied rate doesn't match my rate controller.....	85
• Sentinel doesn't display speed.....	85
• Rate Control Troubleshooting, Manual and Auto Operation Tests.....	86

E

Trouble-
Shooting

Care & Maintenance

• Cleaning.	87
• Winterization	87
• Pre-season Service.....	87

F

Care &
Maintenance

Sentinel Accessories

• Mounting Brackets.	88
• ISO Extensions	88
• Height Switches	88
• GPS Speed Receiver.....	88

G

Accessories



Safety

TAKE NOTE! THIS SAFETY ALERT SYMBOL FOUND THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY AND THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.



**THIS SYMBOL MEANS
ATTENTION!**

BECOME ALERT!

YOUR SAFETY IS INVOLVED!

Note the use of the signal words DANGER, WARNING and CAUTION with the safety messages. The appropriate signal word for each has been selected using the following guidelines:



DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations typically for machine components which, for functional purposes, cannot be guarded.



WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.



CAUTION: Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE is used to address safety practices not related to personal safety.





Hydraulic Fluid and Equipment Safety

This system uses hydraulic equipment with hydraulic fluid under extremely high pressure.

Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin causing serious injury. Keep all hoses and connections in good serviceable condition. Failure to heed may result in serious personal injury or death. Avoid the hazard by relieving the pressure before disconnecting lines or performing work on the system.

Make sure hydraulic fluid connections are tight and all hydraulic hoses and lines are in good condition before applying pressure to the system. Use a piece of paper or cardboard, NOT BODY PARTS, to check for suspected leaks. Wear protective gloves and safety glasses or goggles when working with hydraulic systems. DO NOT DELAY!

Check hydraulic hoses and fittings frequently. Loose, broken, and missing hardware can cause equipment to not perform properly and can result in serious injury or death. Hydraulic systems can be hot and cause burns. Before working on any system, wait until the fluid has cooled.

If an accident occurs, see a doctor familiar with this type of injury immediately. Any fluid injected into the skin or eyes must be treated within a few hours or gangrene may result.

A Word to the Operator



It is YOUR responsibility to read and understand the safety messages in this manual. YOU are the key to safety.

SAFETY IS YOUR RESPONSIBILITY.

SurePoint Ag Systems



General Description

A

Introduction

You have purchased a SurePoint Sentinel system for your equipment. This system will be controlled by the Sentinel ECU through your in-cab ISO display. If you are using the Sentinel for row monitoring, your liquid system will continue to function as usual with application rates being regulated by your existing rate control. The Sentinel works independently, monitoring the row-to-row accuracy of your system and alerting the operator of over-applying, restricted or blocked rows.

If you are using Sentinel for Rate Control, the Sentinel ECU will be the rate controller for your system.

SurePoint currently supports Sentinel operating on the following displays: **John Deere** 2630 & 4640, **Ag Leader** InCommand 800 and 1200, **Case IH** Pro 700 and Pro 1200, and **Trimble** TMX-2050. The use of Sentinel on any other display may result in diminished functionality.

A 2-pin Molex power and 12-pin Ampseal Power/CAN connector are required on your implement to connect the Sentinel ECU to the implement bus. While some equipment manufacturers already provide this connection, SurePoint offers harnessing to provide this connection on any implement. Ask your SurePoint representative what accommodations may be needed for your specific equipment.

Basic Installation Steps for Row Monitoring

1. Manifold together the Sentinel flow modules as necessary to obtain the correct section-control configuration.
2. Mount the Sentinel flow modules as necessary using existing or provided brackets and hardware.
3. If necessary, route the provided ISO extension cable from the implement hitch to the desired Sentinel ECU mounting location.
4. Locate the 2-pin Molex power and 12-pin Ampseal POWER/CAN connectors that the Sentinel ECU will be connected to and remove the terminator.
5. Mount the Sentinel ECU using the provided bracket in a location within 4 feet of the above connection.
6. Attach the Sentinel ECU harness (208-06-____Y2) to the Sentinel ECU and plug the other end of the harness into the above Molex/Ampseal POWER/CAN connection.
7. Use the previously removed terminator to terminate the POWER/CAN connection found on the ECU harness.

Follow steps 8-11 if using Sentinel Flowmeter Modules:

8. Locate the CAN Trunkline harness (208-06-29XX) and plug the 4-pin Amp Superseal connectors into the open connection on Flow module(s) as shown on page 7.
9. Route this harness to the ECU harness, using 4-pin Deutsch extensions when needed.
10. Locate the "Flowmeter Bus" connector on the ECU harness. Remove the terminator (208-06-2912Y1) and plug the 4-pin Deutsch from the flow modules into this connection.
11. Move the terminator to the open 4-pin connector on the end of the CAN Trunkline harness.
12. From the in-cab display, address the flow modules and configure the implement as outlined in the setup instructions in this manual using the tab for the system you have.


System Overview Example 1

The following gives an example of a complete SurePoint Fertilizer system with these components:

- Tank
- Pump
- Section Valves
- Sentinel Flow Monitor
- Check Valve
- Optional: Dual metering tube plumbing

B

Components
Liquid




System Overview Example 2

B
Components
Liquid

The following gives an example of a complete SurePoint Fertilizer system with LiquiShift and these components:

- Tank
- Pump
- LiquiShift Valve Stack
- Sentinel Flow Monitor
- Zip Valves or Check Valves



Parts and Fittings Manifold Feed



ITEM NO.	PART NUMBER	DESCRIPTION
1	204-01-4625AAGB1B1	Sentinel™ Flowmeter Module
2	120-T3MT3F-4XT1M	T3 Male/Female Manifold w/ (4)T1 Male Outlets
3	124-02-010003	T3 Fork
4	120-T3FTEE	T3 Tee
5	120-T3MPLUG	T3 Male FC Plug
6	124-02-010004	T4 Fork
7	120-T4FT3FRC	T4 Female x T3 Female FC Reducer Coupling
8	120-T4MT3MRN	T4 Male x T3 Male FC Reducer Nipple
9	121-T3M075-90	T3 Male FC x 3/4" HB - 90 degree
10	121-T3F075	T3 Female x 3/4" HB
11	124-01-G11056-V	Viton O-Ring for T1 fittings
12	124-01-G11058-V	Viton O-Ring for T3 fittings
13	124-01-G11054-V	Viton O-Ring for T4 fittings

See next page for a list of T1 fittings

Parts and Fittings for Isolated Rows



Commonly used Quick-Connect (QC) Fittings

Part Number	Description
113-12-038038	Stem Elbow—3/8" Stem x 3/8" QC
113-05-025	Plug - 1/4" QC
13-05-038	Plug - 3/8" QC


T1 Fittings

Part Number	Description
120-T1M038QC	T1 Male x 3/8" QC
120-T1M025QC	T1 Male x 1/4" QC
121-T1M038	T1 Male x 3/8" HB
121-T1M050	T1 Male x 1/2" HB
124-01-G11056-V	Viton O-ring for T1 Fittings

Sentinel Flow Meter

Part Number	Description
204-01-4625AAGB1B1	4-Row Sentinel flow meter
124-02-010001	T1 Fork
374-4024Y1	4-Pin Amp Superseal dust plug
384-1105	Hardware Kit - mounting bolts

SurePoint Harness Layout for ISO Sentinel



The SurePoint Sentinel module communicates with the Sentinel ECU through a proprietary communication network (CAN). The Sentinel ECU then, using the ISOBUS communication protocol, relays the flow information through the tractor ISOBUS and generates the user interface on the in-cab display. A series of connections are required to form this communication network.

Tractor Connection

Designed to integrate with any implement, in some cases, connecting the Sentinel starts at the tractor's ISOBUS connection. Power and information is relayed to the Sentinel ECU using a SurePoint Front ISO Extension which includes power and CAN bus connections. Already using the tractor ISOBUS? No Problem. SurePoint carries ISOBUS-Y harnesses to split the ISO connection at the tractor.

Implement Height and Speed Input


Not used in all configurations, the implement height and speed input connections provide additional input options in situations that require advanced alarm control and an auxiliary speed source. These conditions generally exist only in hybrid systems, utilizing multi-branded components.

Sentinel and LiquiShift

The Sentinel ECU has incorporated software that allows for customized control of up to 2 SurePoint LiquiShift systems. When used, the ECU replaces the LiquiShift Controller.

Service Connections

The Terminating Resistor, Programming and RS232 connectors are for service only and should not be used.




Bus Connections

2 Bus connections are provided for convenience so that each side of the implement can plug into the ECU harness without the need for a long, continuous chain of connections.


SurePoint Harness Layout for ISO Sentinel


C


Components
Wiring & Elec.



The Sentinel flowmeter module is chained together with other modules using the provided trunklines and then later assigned an implement location within the display. The trunkline is connected to the Sentinel module through the port labeled **+12Vdc** while the remaining port is plugged. CAN connections cannot be left open. When a terminator is removed to plug in a trunkline, the terminator must be moved to the end of the trunkline. It is not required to utilize both Bus connections on the main harness. If Meter Bus 2 is not used, plug a terminator in to that connector.







1

2

3

4

5

6


208-06-5022Y1

Sentinel Rate/Row Control ECU Harness - 2 Product - 18 Sections

X-048
Sentinel ECU


Sentinel ECU
Type B 81-pin
1473244-1

Part 1 of 4



X-050
Speed Input

MP-150 Tower 3-pin
12110293



Speed Input - not used very often. Only used if a separate radar or GPS speed sensor is used on implement. Select *ECU Input Speed*. + 12v between B&C.

Flow Meter BUS--Use BUS 1 and/or BUS 2 for trunkline/extensions to Sentinel modules. Must have a terminator (2912) on the end of each BUS line.

+ 12v between 4&1.


+2.5 +/-1v between 3&1.

+2.5 +/-1v between 2&1.

X-001
Flow Meter BUS 1

Add 208-06-2912Y1
Terminator


4 PIN Deutsch Tower
DT06-4S



X-004
Flow Meter BUS 2

Add 208-06-2912Y1

4 PIN Deutsch Tower
DT06-4S



208-06-5022Y1 replaced 208-06-4099Y_
The pinouts are the same.

4099 had resistors needed by the KZ valves it was sold with.

1

2

3

4

5

6

Sentinel ECU

Part 2 of 4


208-06-5022Y1

**Sentinel Rate/Row Control
ECU Harness - 2 Product - 18 Sections**

X-033

RS232


WP Shroud 3-pin
12010717



X-040

Programming


Deutsch Shroud 4-pin
DT04-4P



Programming CAN Term.

X-054

Deutsch Shroud 3-pin
DT04-3P



A

B

C

1

2

3

4


5

6

X-048 Sentinel ECU

Part 3 of 4


Sentinel ECU
Type B 81-pin
1473244-1



208-06-5022Y1 Sentinel Rate/Row Control ECU Harness - 2 Product - 18 Sections


X-003 LS Controller Product 1

Deutsch Shroud 8-pin
DT04-08PA



X-002 LS Controller Product 2

Deutsch Shroud 8-pin
DT04-08PA





Implement Switch


+ 8.2v or 12v between B&A.
Jump between A&B for testing or emergency use.


Implement Switch


WP Tower 2-pin
12015792













208-06-5023Y1 replaced 208-06-4701Y_

The pinouts are the same.

4701 had resistors needed by the KZ valves it was sold with.








208-06-5022Y1 Connector pinouts for Rate Control and Row Control







ISO Connector - 12-pin



Flowmeter Bus 1 & 2




General Diagnostic Tips
+12




208-06-5023Y1 Connector pinouts for Gen3 LiquiShift Rate Control



Product 1




Product 2




The connectors not shown here are the same as on the 5022 harness on the previous page.

Left Sections



Right Sections




4-Pin Deutsch CAN Trunklines to 4-Pin AMP SuperSeal to connect Sentinel Flowmeter Modules


Part #	Number of flowmeter connectors	Length
208-06-2908Y2	1	5'
208-06-2909Y2	1	15'
208-06-4975Y1	2	5'
208-06-2910Y2	2	15'
208-06-2911Y2	3	15'
208-06-4976Y1	4	5'
208-06-4977Y1	4	15'

2908 and 2909 with one Device connector

CAN Device
+12v between 2&1.
2.5 +/-1 v between 3&1.
2.5 +/-1v between 4&1.



4975 and 2910 with two Device connectors



CAN Bus
+ 12v between 4&1.
+2.5 +/-1v between 3&1.
2.5 +/-1v between 2&1.

2911 is similar to the above, but with three Device connectors.

4976 and 4977 are similar to the above, but with four Device connectors.


The Deutsch 4-pin Tower CAN Bus connector (bottom right of each drawing above) is plugged into another trunkline or, if it is the last trunkline, it is plugged into a Terminator.

214-00-3553Y1 Thru 214-00-3557Y1

Front Extension Harness – (9-Pin ISO Connector w/ 3-Pin Master Switch & 12-Pin ISO and 2-Pin Molex Power)

Wire 18AWG
unless otherwise
specified

+ Use this for troubleshooting harnessing, voltage, or communication issues. Some issues may need to be traced back to the 9-pin ISO connector. There is a fuse between the 9-pin ISO connector on the back of the tractor and the battery.



+ **2-pin Molex Power**
+ 12-13v between 2&1.
+ The pins in here can get pushed back and not make contact.


12-pin ISO connector
+ 12-13v between 2&1
12-13 v between 9&3
2.5+/-1v between 4&3
2.5+/-1v between 10&3

How to get to Sentinel on the VT (or UT)


D

Setup & Operation

John Deere 2630 Display



Pro 700 Display




You can set up VT Upload and VT Implements on Toolbox > Layout (shown in Left Area above). On first bootup, VT Upload may take several minutes for a new device.

Press ISOBUS to go to ISOBUS devices or Press the Sentinel icon to go to the Sentinel screens.

John Deere 4640 Gen 4 Display



PRESS "ISO" to go to the ISOBUS VT screens. There may be more than one ISOBUS device connected.




ISOBUS VT Menu

There may be more than one ISOBUS device connected.

How to get to Sentinel on the VT (or UT)

Ag Leader InCommand



D

Setup &
Operation

Trimble TMX-2050

Icons from Sentinel

D

Setup &
Operation



Sentinel Wheat "HOME" button - returns to the main run screen.



IMPLEMENT Setup - enter implement geometry



SPEED Setup - select speed source and see which speed sources are reporting speed.



HARDWARE - set up height switch, master switch, task control, Intellisec-tion



RATE Setup - set up rate mode, target rate, rate smoothing




SETTINGS tools - set up products, devices, rows, sections



ROW BAR - see Sentinel row graphs depicting the flow on each row



SureFire(Point) - see software version. Go to Auxiliary Settings screen.



Next VT - when more than one display is in use, this moves the Sentinel to the next screen. (v.1.3.0)



Save to this VT - when more than one display is available. (v.1.3.0)



Nozzle Test - Run a test with a simulated speed and target rate. (v.1.3.0)



Catch Test - check and adjust flowmeter calibration. (v.1.3.0)



Save Task Controller settings



LiquiShift - this icon will be available when Sentinel is controlling the LiquiShift valves.

Sentinel Startup Light Sequence to identify Sentinel Multiflow Modules

After the Sentinel has been set up, when the Sentinel is turned on there will be some lights that light up on the flowmeter units. The Sentinel Multiflow unit that contains Rows 1-4 (Multiflow 1) should have an alternate flashing of lights A-B and C-D. (A-B, C-D, A-B, C-D, A-B, C-D, A-B, C-D, A-B, C-D). While these lights are flashing on Multiflow 1, Multiflow 2 (Rows 5-8) should have light B lit. Multiflow 3 (Rows 9-12) should have lights A & B on. Multiflow 4 (Rows 13-16) should have light C on.

The address of any module can be confirmed by unplugging it and watching the light pattern as it is plugged in.

Multiflow Module 1 will alternately flash A-B, C-D several times when the Sentinel is turned on.



1 2 4 8

Multiflow Module 2 will show light B when the Sentinel is turned on.



Multiflow Module 3 will show lights A & B when the Sentinel is turned on.



Multiflow Module 4 will show light C when the Sentinel is turned on.

$6 = 2 + 4$ $7 = 1 + 2 + 4$
 $9 = 1 + 8$ $10 = 2 + 8$ $11 = 1 + 2 + 8$
 $12 = 4 + 8$ $13 = 1 + 4 + 8$ $14 = 2 + 4 + 8$
 $15 = 1 + 2 + 4 + 8$



Module 5

should have lights A & C (1 + 4) come on for 3 seconds when it is plugged in. Unplug the module, watch the lights as you plug it back in.

Other LED Signals

When liquid is flowing, there will be a flashing of LEDs on the channels with flowing liquid, with the frequency proportional to the flowrate.

When liquid is not flowing, the LED on each channel will be lit to indicate there is liquid in the unit. (These lights will blink off shortly once every 3 seconds.)

When liquid is not flowing but is present in the flowmeter, if the LED is OFF (with a short blink every 3 seconds), that indicates the flowmeter on that row is not detecting any liquid. If all rows are like this, it could indicate a low conductivity fluid that the units will not read. If one or two rows are like this, it could be a marginally conductive liquid or faulty flowmeter on that channel. Clean the inside tube with a soft cloth.

Setting Up

D
Setup &
Operation

Sentinel Row Monitoring With Sentinel Flowmeters



226-01-3547Y1
Sentinel ISOBUS ECU
Level 2 ECU



OR

226-01-5319Y1
3CS Row Monitoring
Sentinel ISOBUS ECU
Level 1 ECU

Typically will use one of the following Sentinel ECU Harnesses

208-06-5021Y1	Sentinel ECU Harness	208-06-5374Y1	Sentinel Lvl 1 Monitor Only
208-06-3536Y3	Sentinel ECU Harness		

Sentinel Setup and Configuration









Set-up and Configuration for Row Monitoring

D
Setup & Operation

The following pages will guide you through the initial set-up and configuration of your Sentinel Row Monitoring system. Below is an overview of the steps necessary to fully configure the system before operation. Each subsequent page outlines the page features as well as the sequence of buttons used to navigate to that page from the HOME screen.

Basic Steps for Initial System Set-up for Row Monitoring

For detailed information on a step, go to the referenced page

STEP	
REFERENCE Page #	
34	1. Press the HOME button 
34	2. Go to the settings page by touching the SETTINGS button 
34-35	3. On the settings page, specify the number of products being monitored (maximum of 4)
34-35	4. Configure each product by touching the PRODUCT button 
35	5. Select DEVICE (<i>Liquid Row Monitor</i>) and set up each product with requested information.
35	6. Press MORE , set up Rate (AVG), Smoothing (10%), other options for this setup.
36	7. When finished, use the BACK arrow to go back to the SETTINGS menu.
36	8. Set up the implement dimensions by touching the IMPLEMENT button. 
36	9. Choose a speed source by selecting the SPEED button. 
36	10. Select system control options (IntelliSection, lift switch, etc.) under HARDWARE . 
37	11. Select the Rate Mode (AVG) at RATE SETUP . 
38	12. From the Settings screen, touch the NEXT button. 
38	13. Click on Flow Module Diagnostics
38	14. Ensure that all flow modules are plugged in and click Reset All Addresses
	15. Unplug all of the Sentinel Flowmeter Modules.
	16. Beginning with module #1 (on Product 1), plug it back in - module 1 should turn green on the screen. Have someone watch the screen to verify successful addressing for each module. Also, watch the lights on the module per Sentinel Startup Light Sequence (p.30).
	17. Moving across the implement, plug in each module for Product 1 in order.
	18. If applicable, address the modules for product 2 by repeating steps 15-17 for product 2.
	19. Select the correct module orientation (ABCD or DCBA) (What is Row 1? (A) or (D)?)
39	20. Customizing Scans and Alarms
40-44	21. Row Detail Screen, LiquiShift setup , Customizable Toolbar, and Operation

Sentinel Setup and Configuration

Home Screen Navigation for Row Monitoring

D


Setup & Operation

Real-time, implement-wide performance is displayed here as both target rate and actual rate

If an implement height switch is plugged into the Sentinel harnessing, there is an arrow showing the current implement height status.

The Row Bar View provides a quick visual reference of total system performance as well as individual row flow.

The black bars represent the user-defined row-flow **tolerance** above and below the current flow




Row Bar Button



The SENTINEL ROW BAR button appears when using row flow monitoring. When doing row flow monitoring, this takes you to the row bar view page (above). This button may appear on the right side of the screen or on bottom left, where it puts the Row Bar View on the bottom half of the screen.

Row Detail Button



Touching the **ROW DETAIL** button will display individual row details including individual row flow, rate, module temperature, voltage, etc. (see page 40) To change the row that is being displayed in this button, touch the row on the flow chart. (see pg. 40)

Customizable Toolbar (Screen Settings)



Touching this button will allow you to set up the icons on this row. When you press this button you will see three rows of icons. The top row shows what is on your screen now. To change an icon, press on that icon on the top row and then press on the icon you want there on the 2nd or 3rd row. Click OK.



Next Product Button


Toggle between up to 4 product screens (Liquid Row Flow Monitoring) by touching the **NEXT PRODUCT** button.



Settings (Tools) Button

The **SETTINGS** button will be used to access the system configuration pages and to change individual product alarm, tolerance, and rate settings. (see next page)

Master (ON/OFF) Button



The **MASTER ON/OFF** button enables and disables the Sentinel system. *This must be **GREEN (MASTER ON)** for Sentinel to work.*

ARROW indicates implement position when using Implement Switch with Sentinel



SETUP for Row Flow Monitoring - Settings - Product - Device

D

Setup & Operation

Prod # 1 Row # 9
GPA 0.0 GPM 0.00
1-Product 1
TARGET GPA 0.0 ACTUAL GPA 0.0
MASTER ON SPEED 0.0 MPH ACTUAL PRESS 0.1 PSI FLOW 0.0 GPM DUTY CYCLE 0.00 %
Manual Section
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
1:54pm
Page 0

- 1.) Press the **SETTINGS** Tools button to go to the System Configuration screens.

Number of Products 1
Current Setup
Product 1
Device LiqRowMon
Rows 16
Sections 4
Spacing 30.0 INCH
Implement Width 40.0 FT
Device
Rows
Sections
Spacing
Implement Width
8:38am

- 2.) Enter the **number of products** that will be monitored or controlled with the Sentinel.

- 3.) Press the big **Product 1** box.

(If the system has two products, there will be a Product 2 box to the right of Product 1. Set up Product 2 in a similar fashion to what is shown for Product 1.)

Product 1
1-Product 1 Name
Device LiqRowMon
Select Device Type
Liquid Row Monitor
NH3 Row Monitor
Liquid Rate Control
Liquid Rate Control + Monitor
CANCEL
8:38am

- 4.) Enter a name for the Product.
- 5.) Press the box under "**Device**".
- 6.) Select "**Liquid Row Monitor**" to use the Sentinel flowmeter modules for row flow monitoring.

SETUP for Row Flow Monitoring - Sections - Rows - Tolerance - Rates - Smoothing - LiquiShift Enable

Product 1
1-Product 1 Name

Device: LiquiShift
Sections: 4
Total Rows: 16
Spacing: 30.0 Inch

Start Row: 1
Implement Width: 40.0 FT
Tolerance: 25.0 %

Sec#	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	4				
2	4				
3	4				
4	4				

Reset Total
Metric Units ☐

More
8:37 am

7.) Enter the number of **SECTIONS** for this product.

8.) Enter the number of **ROWS** for this product.

9.) Enter the row spacing in **INCHES**.

10.) **Start Row** = 1 for Product 1.

Product 2 Start Row will typically be 1 more than the number of Rows on Product 1. On a 16-row system, Product 2 will start with Row 17.

11.) Enter **Implement Width** in FT.

12.) **Tolerance** - start at 25%. You can lower this in the field. If the tolerance is too low, there will be unnecessary alarms. The Row Bar Graph will show red if a row is off-rate by the Tolerance % or more. *Tolerance* sets the black bars on the Row Bar View graph.

13.) Verify the number of rows in each section.

14b.) Press **More** to go to the next screen.

14a.) Check this box for **Metric Units**.

15.) See below: **Rate Mode** - For row monitoring set this to **AVG**. Sentinel will report how far from average each row is. For systems with less than 6 rows, set **User Def** and enter the rate.

Product 1
1-Product 1

Rate Mode: AVG
Rate: 9.00
Row Smooth: 10 %

User Defined Manual Rates
1.00 7.00 00

Outside Row Rates
First: X 1.0 Last: X 1.0

Interplant Mode: Disabled

LiquiShift Enable: ☒

LiquiShift A/B Close On Stop: ☒

ENABLE ALL ROWS
ABCD
DCBA

10:18 am

16.) **Smoothing** - Start with 10%. Typical setting will be from 5 to 15%.

The green line on the Row Bar Graph will be a thin line if the row variation is less than the Row Smoothing %.

17.) For Row Monitoring with Rate Mode set to **AVG**, you do not need to enter any rates.

18.) **Rate for Outside Rows** is typically "X 1.0".

Some applications may be "X 0.5" (half-rate) or "X 1.5" (rate and a half) for outside rows.

19.) **Interplant Mode** -


20.) **LiquiShift Enable** - Check this box if Sentinel is controlling LiquiShift on this product. (LiquiShift A-B valves can be controlled by a black LiquiShift Control Module on the back of the A-B Valve stack or can be plugged into and controlled by the Sentinel.)

21.) **LiquiShift A/B Close on Stop** - Typically this is not checked.

22.) **Module Orientation** - **ABCD** if Row 1 is A. **DCBA** if Row 1 is D on the Sentinel flowmeter module (typical).

23.) Press the **Back Arrow** when finished with this screen.

SETUP for Row Flow Monitoring - Implement - Speed - Hardware




24.) Press **Implement** to enter and verify the Implement geometry.

The Implement dimensions are used when Task Control is enabled. This will not usually happen when Sentinel is only used for row monitoring.

A = distance from Hitch to implement pivot (axle)
B = implement offset (left or right)
C = distance from Implement pivot (axle) to application point

(This combines with the geometry set up in the controller for the position of the GPS in relation to the hitch)

Press the Back Arrow when finished.




25.) On the right side, Press **Speed**.

Press the top box to select the Speed Source. This is typically Ground Speed.



26.) Check this box while moving to see which speed sources are reporting.

27.) On the right side, press **Hardware**.




28.) **Use Master Switch** - check this box if a dedicated Master Switch (Foot Switch) is plugged into Sentinel. This is usually not used for row monitoring systems.

29.) **Use Height Switch** - Check this only if the Sentinel has a dedicated height switch. This is usually not used for row monitoring.

30.) **Setup** if necessary for correct orientation of height switch.

31.) **Enable Task Control** - normally not used for row monitoring.

32.) **Enable IntelliSection Technology** - used for row monitoring when Task Control is not used.



SETUP for Row Flow Monitoring - Rate Setup - Smoothing - Flow Adjustment

Product 1
1-Product 1

33 Rate Mode: Avg Rate: 9.00 Rate Smooth: 10 % ☒

34 Flow Adjustment: 1.00 Reset Totals... Row Smooth: 10 % ☒

User Defined Manual Rates
1.00 7.00 9.00

Outside Row Rates First: X 1.0 Last: X 1.0

Interplant Mode: Disabled

LiquiShift Enable: ☐

LiquiShift A/B Close On Stop: ☐

10:18am

33.) For Row Monitoring verify the Setting is **AVG**. Smoothing usually starts at 10%. You do not need to enter a rate when it is set to AVG.



34.) **Flow Adjustment** - Use this to synchronize the Sentinel flowmeter modules with the main system flowmeter. Once the accuracy of the main flowmeter has been confirmed, change the Flow Adjustment factor as needed to synchronize the Sentinel reading with the main flowmeter reading.

$$\frac{\text{Main Flowmeter GPM}}{\text{Sentinel Total Flow GPM}} =$$

Flow Adjustment Factor

(Generally between 0.95 and 1.05)

On software version 1.3.0 and later, the Flow Adjustment factor can be set for each row on the Row Detail Screen if an individual row is reading incorrectly (see page 40).

SETUP for 2 products with Row Flow Monitoring

SENTINEL

Number of Products: 2

Current Setup

	Product 1	Product 2
Device	LiqRowMon	LiqRowMon
Rows	16	16
Sections	2	2
Spacing	30.0 INCH	30.0 INCH
Implement Width	40.0 FT	40.0 FT

Device: _____
Rows: _____
Sections: _____
Spacing: _____
Implement Width: _____

12:06pm

Product 2
2-Product 2

Device: LiqRowMon Sections: 2 Total Rows: 16 Spacing: 30.0 Inch

Start Row: 17 Implement Width: 40.0 FT Tolerance: 25.0 %

Sec#	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	8				
2	8				

Reset Total Metric Units

12:06pm


If you are setting up Sentinel to do row monitoring on 2 products your screen will look like this. You will need to go through the setup steps for both Product 1 and Product 2.

Sentinel Flow Module Setup and Configuration

Addressing Sentinel Flow Modules

D

Setup & Operation



Flow Module Diagnostics


To address the Sentinel flow modules, start by having all the modules plugged in. From this screen, push **Reset All Addresses**. This sends a message to the modules to erase their address. All modules for Product 1 are then unplugged and then plugged back in, in order across the machine. As each module is plugged in, Sentinel identifies its location on the machine and the module is then given its new address and it will turn green on the screen. *Have someone watch this screen to be sure each module is recognized as it is plugged in.*

If there is a problem with modules not addressing, be sure the tractor is running to keep the voltage up.


Once all modules are addressed, choose the proper **orientation** as described below.

Repeat for each Product.

Flow Module Diagnostics Screen




OR




Most machines will have the modules mounted facing forward, causing Row 1 to correspond with row D on the module. Therefore, the orientation DCBA must be selected. Likewise, if the modules are mounted rear-facing, the orientation ABCD will be selected.



Press the toggle button to go to the next page of modules if needed.



Example 16-Row—D C B A Orientation




Customizing Scans and Alarms for Row Monitoring




D
Setup &
Operation

This screen allows the user to change how row information is displayed on the HOME screen.

- 35.) When checked, the **Auto Scan** feature will scan through the product pages and/or rows on the HOME screen. You can change the length of time it stays on each page or row before advancing.
- 36.) **Auto Hide Alarms (if checked)** sets how long full-page alarms are displayed before they go away.
- 37.) **Disable Alarms** - Check this to turn off alarms. May want to do this for testing or troubleshooting.
- 38.) **Alarm Time** - how long a row must be outside of the specified tolerance before the alarm sounds.
39. **Re Alarm Interval** - The time before the Alarm alarms again after being acknowledged. If the issue that triggered the alarm is not resolved, it will keep alarming at this interval until resolved (if the box is checked).
40. **Bus Update Interval** - Use this to slow down ISOBUS traffic if the BUS load is too high. *Reset only after talking to a SurePoint representative.*
- 41.) **Flow Module Diagnostics** - Flow Module Diagnostics are addressed on previous page.
- 42.) **Store Object Pool** - Stores the current ISOBUS layout on the VT.
- 43.) **Delete Object Pool** - Deletes the current object pool on the VT and forces the monitor to regenerate the display when it is rebooted.
- 44.) **Next VT** - press to push Sentinel to another virtual terminal. This may be necessary if there is more than one monitor or display in the cab.



Row Detail Screen - Software Version - Auxiliary Settings



45.) Pressing the Row Detail button (top left corner) on the Run screen brings up the Row Detail Screen.

The bar graph for Rows 1-16 shows the flow in each row at that instant.

A thin green line means the flow varies less than the Smoothing Factor % from the correct amount.

A thicker green line means the flow on that row varies by more than the Smoothing Factor % but less than the Tolerance %.

A red bar indicates the flow on that row varies by more than the Tolerance % set up for that product.

Example: Smoothing Factor - 10%


Tolerance - 20%

Flow less than 10% variance - thin green line

Flow with 10-19% variance - thicker green band

Flow more than 20% variance - red band

Row Detail Screen



46.) Press the Left Arrow or Right Arrow to see details for other rows.



47.) A Row can be ENABLED or DISABLED by checking or unchecking the **ENABLED** box.

48.) **Flow Adj:** Fine-tune the flowmeter on this row here.

49.) Press the SurePoint icon to see the software version number and Sentinel ECU number (see bottom left picture).

50.) **Auxiliary Settings Screen-** Press the sunburst. *Do Not Change anything unless directed by SurePoint Tech Support.*

51.) **Use LS Conn for Press(ure)** - Check this box if using the Sentinel to control LiquiShift while using 3rd party rate control so pressure will display on rate control run screen.




Sentinel Row Monitoring and SurePoint LiquiShift

SurePoint LiquiShift can be controlled through the Sentinel ECU or through a LiquiShift Controller Module (black box-PN 218-2565Y1). *If your LiquiShift has this black box, Sentinel is NOT controlling LiquiShift and you do not need to do this setup.* Many times, Sentinel will be used to control LiquiShift, and the LiquiShift Controller Module is not needed. To activate LiquiShift on Sentinel, follow these buttons:




Using Sentinel to control your LiquiShift eliminates the need for the LiquiShift Controller module (218-2565Y1). This is a black module that would be on the back side of the A-B LiquiShift valves.

If this module is not there, an 8-pin harness extension (206-08-XXXX) is added from the Sentinel ECU harness (LS Controller connector) to the LiquiShift Controller plug on the pump final harness (Gen3 LS) or on the Manifold Controller (3454) harness (Gen2 LS). The Sentinel gives the operator absolute control over the LiquiShift shift points, real-time pressure readings, and provides in-cab manual control. For more information regarding the use of Sentinel in controlling your SurePoint LiquiShift, refer to your LiquiShift system manual.



Setting LiquiShift shift points



Standard High Pressure Up Shift Point: 70 PSI

Standard Low Pressure Down Shift Point: 20 PSI

If these shift points are not set correctly, the LiquiShift may not work or may work very erratically. They must be set so that when the valves switch, there is appropriate pressure in the new tube to keep the system operating smoothly.

For example, if the shift points are set at 50 PSI and 25 PSI, the valves will switch from A to B when the pressure in tube A reaches 50 PSI. This flow in tube B may only build 15 PSI, so it will immediately switch back to A. Since the pressure there is 50 PSI or more, it will switch to B. The system will switch back and forth repeatedly causing wild pressure rate and pressure fluctuations.

There may be situations where it may work better to use something other than a 70/20 PSI setpoint, but don't set other numbers without knowing what you are doing.




For typical operation, this box is NOT checked.




Green - Valve is ON.


Operating Sentinel Row Monitoring TURN IT ON



(10) Press this Row Bar View button to take out the middle section of the screen above, and show the screen below - the **Row Bar View** (normal Run Screen view for monitoring).



Customizable Toolbar



For Sentinel Row Monitoring to work,

- (1) MASTER ON button must be green, and (2) the Product ON/OFF button must be green.
- (3) For Row Monitoring, Rate Mode is normally AVG.
- (4) Sentinel will not operate until a SPEED is registered. Enter simulated speed here.
- (5) The system pressure will not read here unless Sentinel is controlling LiquiShift, but will be shown on the Rate Controller screen.
- (6) Set up Total Flow / Min for this reading measured by the Sentinel flowmeter modules.
- (7) Set up Avg Flow / Area for this reading measured by the Sentinel flowmeter modules.
- (8) Manual Sections doesn't do anything for Row Monitoring. It works with Rate Control.
- (9) Press this button to select which icons show up on this row of buttons. (see #14 below)

- (11) **Row Detail button** scrolls through row by row to show the GPM and GPA measured by the Sentinel flowmeter on each row. Press on this box to see more row details.
- (12) When doing only Row Monitoring with the Sentinel set to AVG Rate Mode, this box shows the average rate currently being applied on all rows as measured by the Sentinel flowmeter modules.
- (13) **Row Detail Bar** gives a bar graph view of the amount currently being applied by each row. The top screen shows a straight thin green line indicating that all the rows are applying with a variance less than the Row Smoothing % that is set. A few rows on the bottom screen show a little wider green bar, indicating a variance that is greater than the Row Smoothing %. The red bar on Row 16 indicates that this row is applying outside the Tolerance % set in the Product setup. The thin black lines above and below the green line show the Tolerance % set in the Product setup. Changing the Tolerance will move those black lines further apart or closer together.
- (14) **Customizable Toolbar** - Press on the gear to select which icons appear on this row. Example: Press on box 4 (None) - Select *Total Flow/Min* from below. Press OK- to have *Flow - GPM* display in box 4 of that toolbar.

Customizable Toolbar & Totalizer Counters - Acres - Hours - Gallons

D

Setup &
Operation

Sentinel has 3 totalizer counters to keep track of acres, hours, and gallons.

Any of these may be set up on the Customizable Toolbar near the top of the Product Run Screen. If these are not on the Customizable Toolbar, the values may still be seen by pressing the *Reset Totals* button on the Rate Setup screen. The items may be individually reset to 0 by pressing the Reset Total button for that item, or the totals may be left unchanged by returning to the Run Screen without resetting the values.

Rate Setup Screen

Sentinel Row Flow Monitoring Operation

D

Setup & Operation

Once the Sentinel has been set up in the display, little is required of the user to operate the Sentinel. The system is designed to run in the background and only alert you if there is a problem. Most Sentinel users will spend a portion of their initial start-up time correcting inaccuracies in row-to-row flow on their implement. As previously mentioned, the HOME screen (Row Bar View) yields a quick snapshot of row-to-row comparisons while the Row Detail report gives more specific information about each row.




Row Bar Button

From the HOME screen, when the flow for a row or rows goes outside the set tolerance, the row will display red in the bar chart. When a row becomes plugged, the rest of the rows will show an increase in flow as product from the plugged row is now sent to the remaining rows. Likewise, if a row begins to show increased flow, such as in the case of a broken hose, the rest of the rows may show a decrease in flow.

Watching this screen for a while will allow you to see what the normal operating range is, so you can adjust the tolerance to avoid false alarms but to get timely notification if there is a problem.


Sentinel HOME Screen for Row Flow Monitoring



Alarm Screen




Row Detail Button



From the HOME screen, touching the row detail button will display the *Row Detail* page. The user can toggle through the rows by touching the < > buttons.

If there is an issue with a row, monitoring of individual rows may be disabled by unchecking the *ENABLED* box on that row.



Fine-Tuning Sentinel Row Flow Monitoring


ISSUE: “My Sentinel does not show the same rate or flow as my rate controller.”

What’s happening: It’s possible that the flowmeter on the rate controller and the Sentinel row flowmeters are not in sync.

Do This: If you are applying 5.5 gal/acre with the rate controller, but the Sentinel shows 5.0 gal/acre (1), do a **catch test** with the regular flowmeter to determine if it is calibrated correctly. Adjust as needed.

Once the rate controller flowmeter is calibrated correctly, then compare the Rate (1) and the Flow (2) with what the Rate Controller shows. If there is a discrepancy, go to the Sentinel Rate Setup screen, and change the Flow Adj. factor.

If the Sentinel is showing too much flow, reduce the Flow Adj. If the Sentinel is reading low, increase the Flow Adj. (Start with 0.95 or 1.05 and fine-tune from there.)




ISSUE: “One row always shows high (or low) flow.”

First: What is the Row Smoothing set at? Recommended starting point is 10%. What is the Tolerance set at? We recommend starting at 25%. These can be adjusted either way.

What’s happening: Two possibilities:


- (1) That row is always applying high or low.
- (2) The row is applying correctly, but the Sentinel is reporting it as high (or low).



Do This: A. Swap hoses or tubes to switch rows at the Sentinel to see what the Sentinel shows. This may give an idea of where the problem is.

B. Do a **catch test** on that row and on a couple rows either side of it.

- (1) If the row is applying high (or low) check the plumbing to that row for any conditions that might be causing the error. If you can find nothing causing the discrepancy, you can increase the flow to a row by shortening a metering tube a few inches. You can decrease the flow to a row by putting a hose clamp around a hose to that row.
- (2) If the row is actually applying correctly, but showing wrong on the Sentinel, change the Flow Adj. on the Row Detail screen. If the Sentinel is reading low, increase the Flow Adj (1.05). If the Sentinel is showing high, decrease the Flow Adj (0.95).
- (3) Fine-tune the Flow Adj as needed.



SurePoint Ag Systems



Setting Up

Sentinel Rate Control

Without Sentinel Flowmeters (No Row Monitoring)



226-01-3547Y1
Sentinel ISOBUS ECU

Typically will use one of the following Sentinel ECU Harnesses

For Rate Control **without Gen 3 LiquiShift**

208-06-5022Y1	Sentinel Row Control and Flow Monitoring ECU Harness- 2 products - 18 sections
208-06-4099Y4	Sentinel Row Control and Flow Monitoring ECU Harness - 2 products - 18 sections
208-06-4984Y2	Sentinel Row Control and Flow Monitoring ECU Harness - 4 products - 18 sections

For Rate Control **with Gen 3 LiquiShift**

208-06-5023Y1	Sentinel Row Control and Flow Monitoring ECU Harness - Gen 3 LiquiShift - 2 PR - 16 sect
208-06-4701Y2	Sentinel Row Control and Flow Monitoring ECU Harness - Gen 3 LiquiShift - 2 PR - 16 sect
208-06-4985Y1	Sentinel Row Control and Flow Monitoring ECU Harness - Gen 3 LiquiShift - 4 PR - 16 sect

Sentinel Setup and Configuration








Set-up and Configuration for Rate Control

D
Setup &
Operation

The following pages will guide you through the initial set-up and configuration of your Sentinel system for Rate Control. Below is an overview of the steps necessary to fully configure the system before operation. Each subsequent page outlines the page features as well as the sequence of buttons used to navigate to that page from the HOME screen.

Basic Steps for Initial System Set-up for Rate Control

For detailed information on a step, go to the referenced page

REFERENCE Page #	STEP	
	1. Press the HOME button	
50	2. Go to the settings page by touching the SETTINGS button	
50	3. On the settings page, specify the number of products being monitored (maximum of 4)	
50	4. Configure each product by touching the PRODUCT button	
50-51	5. Select DEVICE - Liquid Rate Control and set up each product with requested information for sections, rows, tolerance, etc.....	
51	6. Select MORE , select Rate Mode , enter Rate and Smoothing (10%).	
51	7. When finished, use the BACK arrow to go back to the SETTINGS menu.	
52	8. Set up the implement dimensions by touching the IMPLEMENT button.	
52	9. Choose a speed source by selecting the SPEED button.	
52	10. Select system control options (task control, lift switch, etc.) under HARDWARE .	
53	11. RATE SETUP - Select the Rate Mode Rx or User Def and enter Rates.	
54	12. RATE CONTROL SETUP (Control Speed, Flow Cal, PWM Settings, etc..)and OPERATION information	
55	13. LiquiShift setup for Rate Control	
56	14. Nozzle Test (v 1.3.0 and later)	
57-58	15. Catch Test (v 1.3.0 and later)	
59	16. Customizable Toolbar and Totalizer Counters	
60-61	17. Rate Control Operation and Setup Summary	

Sentinel Setup and Configuration

Home Screen Navigation for Rate Control

D

Setup & Operation

Sentinel Home Screen for Rate Control.


Identifies this screen as showing Product 2.

If an implement height switch is plugged into the Sentinel harnessing, there is an arrow showing the current implement height status.

Target and Actual Rate shown. Green buttons indicate product is ON.

Operate, Setup, & Diagnostic tabs for Rate Control setup, operation, and troubleshooting diagnostics.


Sentinel HOME Screen



BUTTONS: Wheat & Row Bar



The wheat button takes you to the Multi-Product RUN SCREEN (below). This button appears on the right side of the screen. Pressing it puts the Operate > Setup > Diagnostic view on the bottom third of the screen, with the Rate Control information in the center section (see above).



The SENTINEL ROW BAR button appears when using Row Flow Monitoring. If using Rate Control without Row Monitoring, this button will not be used.

Customizable Toolbar (Screen Settings)




Touching this gear button will allow you to set up the icons on this **Customizable Toolbar** row of the screen. When you press this button you will see three rows of icons. The top row shows what is on your screen now. To change an icon, press on that icon on the top row and then press on the icon you want there on the 2nd or 3rd row. Click OK.



Toggle between product screens by touching the **NEXT PRODUCT** button.



The **SETTINGS TOOLS** button will be used to access the system configuration pages for Product setup and to change individual product alarm, tolerance, and rate settings.



The **MASTER ON/OFF** button enables and disables the Sentinel system. This must be **GREEN (MASTER ON)** for Sentinel to work.

ARROW indicates implement position when using Implement Switch with Sentinel



SETUP for Rate Control - Settings - Product Setup - Device Type

D
Setup & Operation

SENTINEL
1-Product 1
Name

MASTER OFF SPEED 5.3 MPH ACTUAL PRESS 0.1 PSI DUTY CYCLE 0.00 % Manual Section

5.0 GPA 0.0 5.00 GPA User Def

Rate 1 5.00 Rate 2 10.00 Rate 3 15.00 DUTY CYCLE AUTO 0.00 % SECTION CONTROL MAN

Operate Setup Diagnostic

Target 5.0 GPA 0 GAL

8:36am

- 1.) Press the **SETTINGS** Tools button to go to the System Configuration screens.

SENTINEL

Number of Products 1

Current Setup

Product 1	
Device	LiqRowMon
Rows	16
Sections	4
Spacing	30.0 INCH
Implement Width	40.0 FT

Device Rows Sections Spacing Implement Width

8:38am

- 2.) Enter the **number of products** that will be monitored or controlled with the Sentinel.

- 3.) Press the big **Product 1** box.

(If the system has two products, there will be a Product 2 box to the right of Product 1. Set up Product 2 in a similar fashion to what is shown for Product 1.)

Product 1

1-Product 1 Name

Select Device Type

Device LiqRowMon Spacing 30.0 Inch Tolerance 25.0 % Num Rows

Start Row 1

Sec# 1 2 3 4

Liquid Row Monitor
NH3 Row Monitor
Liquid Rate Control
Liquid Rate Control + Monitor

CANCEL

8:38am

- 4.) Enter a name for the Product.
- 5.) Press the box under "**Device**".
- 6.) Select "**Liquid Rate Control**" to use the Sentinel ECU to do rate control for the liquid application system.

SETUP for Rate Control - Product Setup - Rate Mode Setup - LiquiShift Enable

D

Setup &
Operation

- 7.) Enter the number of **SECTIONS** for this product. *See note for Gen3 LiquiShift below.
- 8.) Enter the number of **ROWS** for this product.
- 9.) Enter the row spacing in **INCHES**.
- 10.) **Start Section** = 1 for Product 1.
Product 2 Start Section will typically be 1 more than the number of sections on Product 1.
- 11.) Enter **Implement Width** in FT.
- 12.) **Tolerance** - start at 25%. This only applies to Row Monitoring (when used).
- 13.) Verify the number of rows in each section.
- 14a.) Check this box for **Metric Units**.
- 14b.) Press **More** to go to the next screen.

- 15.) See below: **Rate Mode** - For rate control, set this to **Rx** (for prescriptions) or to **User Def** to enter preset rates. Enter the main target rate in **Rate**.

- 16.) **Smoothing** - Start with 10%. If the actual rate at any time is within this % of the Target Rate, the display will show the Actual Rate as being equal to the Target Rate.
- 17.) You can enter up to 3 user-defined rates. These can also be entered on the Rate Setup screen.
- 18.) **Rate for Outside Rows** is typically "X 1.0".
Some applications may be "X 0.5" (half-rate) or "X 1.5" (rate and a half) for outside rows.
- 19.) **Control Integral** - 0.10
- 20.) **LiquiShift Enable** - Check this box if Sentinel is controlling LiquiShift on this product (typical if using LiquiShift). (LiquiShift A-B valves can be controlled by a black LiquiShift Control Module on the back of the A-B Valve stack or can be controlled by the Sentinel.)
- 21.) **LiquiShift A/B Close on Stop** - Typically this is not checked.
- 22.) Press the **Back Arrow**.


*Gen3 LiquiShift systems may have different section setups. Check the section harness to see which section the last row is assigned to in order to determine total number of sections for each product.

12 rows	12 sections	Gen3 LiquiShift	12 rows	6 sections
16 rows	16 sections		16 rows	8 sections
24 rows	12 sections		24 rows	8 sections

One product

Two Products

SETUP for Rate Control and Row Flow Monitoring - Implement - Speed - Hardware




24.) Press **Implement** to enter and verify the Implement geometry.

The Implement dimensions are used when Task Control is enabled. Task Control is normally enabled for Rate Control. Task Control is needed for Section Control and Mapping.

A = distance from Hitch to implement pivot (axle)
B = implement offset (left or right)
C = distance from Implement pivot (axle) to application point
(This combines with the geometry set up in the controller for the position of the GPS in relation to the hitch)


Press the Back Arrow when finished.



25.) On the right side, Press **Speed**.

Press the top box to select the Speed Source. This is typically Ground Speed.

26.) Look at this box while moving to see which speed sources are reporting.



27.) On the right side, press **Hardware**.

28.) **Use Master Switch** - check this box if a dedicated Master Switch (Foot Switch) is plugged into Sentinel. Quite often used for Rate Control.

29.) **Use Height Switch** - Check this only if the Sentinel has a dedicated height switch. Quite often used for Rate Control.

30.) **Setup** - to set up a height sensor or to change orientation of switch.

31.) **Enable Task Control** - normally used for Rate Control. Also, must activate Task Control on display.

32.) **Enable IntelliSection Technology** - not usually used for Rate Control when Task Control is used.

SETUP for Rate Control - Rate Setup - 2 Products - Version Number - Auxiliary Settings

Product 1
1-Product 1

Rate: **33** User Def, Rate: 6.00, Rate Smooth: 10 %, [Checkmark]

Flow Adjustment: **34** 1.00, Reset Totals: **35**, Row Smooth: 10 %, [Checkmark]

User Defined Manual Rates: 6.00, 7.00, 8.00

Outside Row Rates: First X 1.0, Last X 1.0

Control Integral (Ki): 0.10

LiquiShift Enable: [Off]

LiquiShift A/B Close On Stop: [Off]

9:00am

33.) For Rate Control, the Setting should be **Rx** or **User Def**. Smoothing usually starts at 10%. You can enter a Target Rate here. Press **Presets** to enter up to 3 User-Defined rates.



34.) **Flow Adjustment** - Only used with Sentinel flowmeter modules.

35.) **Reset Totals** - Press to bring up Gallons, Time and Acres totalizers.

35

Reset Total Volume: 107.5 GAL

Reset Total Time: 0.7 HR

Reset Total Acres: 15.58 AC

Done

SETUP for 2 products with Rate Control

SENTINEL

Number of Products: **2**

Current Setup

	Product 1	Product 2
Device	LiqRateCont	LiqRateCont
Rows	16	16
Sections	2	2
Spacing	30.0 INCH	30.0 INCH
Implement Width	40.0 FT	40.0 FT

Device: _____

Rows: _____

Sections: _____

Spacing: _____

Implement Width: _____

3:35pm

Product 2
2-Product 2

Device: LiqRateCont, Sections: 2, Total Rows: 16, Spacing: 30.0 Inch

Start Section: 3, Implement Width: 40.0 FT, Tolerance: 25.0 %

Sec#	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	8				
2	8				

Reset Total

Metric Units: [Off]

3:35pm

If you are setting up Sentinel to do Rate Control on 2 products your screen will look like this (above). You will need to go through the setup steps for both Product 1 and Product 2.

Auxiliary Settings Screen

37

SureFire

Sentinel ECU Version: V.1.2.4

Sentinel ECU Serial #: 366428

OU81200000000000000000BR549

A00A80005D40000A

000000000000000000

8:44am

36.) Press the SureFire(Point) icon to see the Sentinel ECU version information.

37.) Press the square by the sunburst to see the **Auxiliary Settings Screen**. **DO NOT CHANGE** these unless directed by SurePoint Support.

Auxiliary Settings Screen

WARNING: Do not change these settings without consulting with a SureFire Ag representative!

Rate/Target At Boom: [Off]

Rate/Target At Bin: [Checkmark]

Rate/Target At Section: [Checkmark]

Bin Enabled: **37** [Checkmark]

Register As Sprayer: [Off] Pro 1200 option

Use Prod2 As Fan Control: [Off]

Use LS Conn For Press: [Off]

Simulate Flow (Demo Only): [Off]


Turn Compensation X Axis: [Off]

ENTER UNLOCK CODE

DEFAULT SETTINGS

10:22am

SETUP for Rate Control - SETUP - Control Speed - Flow Cal - PWM Max and Min



38. From the Sentinel HOME screen, press the center **SETUP** tab.

Start with the following settings. Adjust as needed.

Ctrl Mode - RATE

Ctrl Speed - PR17 - 250-300 PR30 - 200
PR40 - 160 D250 - 150
Tower Electric - 2000-2500

Adjust as needed in the field. Increase the Ctrl Speed if the pump is slow to adjust. Decrease the Ctrl Speed if the pump fluctuates and will not lock on to the rate going across the field.

RPM Cal - 15 (for hydraulic pumps equipped with RPM sensor)

Max RPM - 500 (Maximum is 550, can set lower)

Flow Cal - 2000 - most hydraulic pump systems
0.6 to 13 gpm flowmeter and larger.
3000 - most electric pump systems
0.3 to 5 gpm and smaller

(Flow cal number is on serial number sticker on side of flowmeter)

PWM Max - 80 to 100 (can be set lower)

PWM Min - 25 for most hydraulic pumps.


5-10 for most electric pumps.

Start Boost - usually 0. Can be set slightly higher than normal PWM Duty Cycle for a startup boost.



Open PWM - Normally RED. Turn to GREEN if you want the pump to continue running for product agitation while you turn around. When doing that, enter a PWM % to set the pump speed for agitation (usually 30-40%)

39. **DIAGNOSTIC TAB** - Observe the system parameters during operation.

40. Press SureFire (Point) to see software version information.



41. Press Sunburst for **Auxiliary Settings**.



Sentinel Rate Control and SurePoint LiquiShift

SurePoint LiquiShift can be controlled through the Sentinel ECU or through a LiquiShift Controller Module (black box-PN 218-2565Y1). Most times, Sentinel will be used to control **Gen3 LiquiShift**, and the LiquiShift Controller Module is not needed. To activate LiquiShift on Sentinel, follow these buttons:




The LiquiShift button will now be displayed on the HOME screen

Gen2 LiquiShift: If the LiquiShift Controller module (218-2565Y1) is mounted on the back side of the A-B LiquiShift valves, the 8-pin LS Controller connector on the Sentinel ECU harness will be plugged into the connector from the black box.

If this module is not there, an 8-pin harness extension (206-08-XXXX) is added from the Sentinel ECU harness (LS Controller connector) to the LiquiShift Controller plug on the Manifold Controller (3454) harness.


The Sentinel gives the operator absolute control over the LiquiShift shift points, real-time pressure readings, and provides in-cab manual control. For more information regarding the use of Sentinel in controlling your SurePoint LiquiShift, refer to your LiquiShift system manual.



Setting LiquiShift shift points



Standard High Pressure Up Shift Point: 70 PSI




Standard Low Pressure Down Shift Point: 20 PSI

If these shift points are not set correctly, the LiquiShift may not work or may work very erratically.

They must be set so that when the valves switch, there is appropriate pressure in the new tube to keep the system operating smoothly.

For example, if the shift points are set at 50 PSI and 25 PSI, the valves will switch from A to B when the pressure in tube A reaches 50 PSI. This flow in tube B may only build 15 PSI, so it will immediately switch back to A. Since the pressure there is 50 PSI or more, it will switch to B. The system will switch back and forth repeatedly causing wild pressure rate and pressure fluctuations.

There may be situations where it may work better to use something other than a 70/20 PSI setpoint, but don't set other numbers without knowing what you are doing.



For typical operation, this box is NOT checked.



Green - Valve is ON.

SETUP for Rate Control - TESTS - Nozzle Test (v 1.3.0 and later)

Test run the system with a simulated speed and target rate.

From the Product Setup page press the Nozzle Test icon.

Be sure MASTER is OFF. Press NEXT.



Product 1

1-Product 1

Device: LiqRowCont Sections: 16 Total Rows: 16 Spacing: 30.0 Inch

Start Row: 1 Implement Width: 40.0 FT Tolerance: 25.0 %

Sec#	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	1	13	1		
2	1	14	1		
3	1	15	1		
4	1	16	1		
5	1				
6	1				
7	1				
8	1				
9	1				
10	1				
11	1				
12	1				

Metric Units

35

14:00

More

Product 1

Nozzle Test

Ensure Master Switch is OFF to proceed with test.

MASTER OFF

Next

14:01

Select which sections you want to run for this test. NEXT.

Enter SPEED and RATE. NEXT.

Product 1

Select Sections to run for Test

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

Prev Next

14:01

Product 1

For the nozzle test, the system will run the previously selected sections at a specified rate. Please enter the information below.

Simulated Speed: 5.0 MPH

Target Rate: 10.0 GPA

Prev Next

14:01

Turn MASTER ON to start the test. **Monitor Actual Rate, Pressure, Flow per Minute, Duty Cycle (%), and Pump RPM (hydraulic pump). These are important parameters of system operation. Know what they are during normal operation.**

Product 1

Nozzle Test

Enable the Master Switch to begin the test. Disable the Master Switch to abort the test.

MASTER ON

Target/Actual Rate: 10.0 / 10.0 GPA

Pressure: 21.9 PSI

Flow Per Minute: 2.0 GPM

Duty Cycle: 25.75 %

Pump RPM: 0.0

Cancel

10:16am

To stop the test, turn MASTER OFF.

If only 1 or 2 rows are on, the system may struggle to maintain a smooth output and rate.

When testing with water, the pressure will be much less than it will be with a heavier, thicker fertilizer. On a system with check valves, some of the check valves may not open at low pressure.

Increase the speed or rate to increase the pressure.

SETUP for Rate Control - TESTS - Catch Test (v 1.3.0 and later)

Verify and adjust the flowmeter calibration.



From the Product Setup page press the Catch Test icon (36). Be sure MASTER is OFF. Press CATCH TEST (37).

Product 2

2-Product 2

Device: **BigRateCont** Sections: **2** Total Rows: **16** Spacing: **30.0** Inch

Start Section: **17** Implement Width: **40.0** FT Tolerance: **25.0** %

Sec#	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	8				
2	8				

Metric Units

36

11:21

Product 2

Catch Test 37

WARNING!!! For an accurate sample make sure that the lines and pump are primed, the different rows sampled catch relatively the same amount and the system pressure is adequate. After changing the flow cal, run another test to verify the setting. Always verify with the area and amount of product used in the field after a calibration change.

If an expected and known volume is already known, enter the information below

Expected Volume: **0.00**
Actual Volume: **0.00**
Current Cal: **600**
Proposed Cal: **600**

Accept New Cal

11:21

Product 2

Catch Test

Ensure Master Switch is OFF to proceed with test.

MASTER OFF

Next

11:22

Product 2

Select Sections to run for Test

1 2

Select which sections you want to run during the test or run with all sections ON.

Next

11:22

Product 1

Catch Test

For the catch test, the system will run the previously selected sections until a specified volume is reached. Please enter the information below.

Enter the information. For better results catch more rows, catch a larger volume, and let the test run longer.

Number Of Rows To Catch: **8**
Simulated Speed: **5.0** MPH
Target Rate: **8.0** GPA
Volume to Dispense Per Row: **16** OZ

Next

11:12am

Product 1

Catch Test

Enable the Master Switch to begin the test. Disable the Master Switch to cancel and abort the test. Once the test is complete, press the Next button.

MASTER ON

Target/Actual Rate: **8.0 / 8.0** GPA
Pressure: **14.8** PSI
Flow Per Minute: **1.6** GPM
Volume Target/Actual: **128 / 54** OZ

The Volume Target is the volume per row multiplied by the number of rows being caught.

Cancel **Next**

11:12am

SETUP for Rate Control - TESTS - Catch Test (v 1.3.0 and later)

Verify and adjust the flowmeter calibration.

While the test is running, the actual rate, pressure, and GPM will be shown. The Volume Target is the volume per row multiplied by the number of rows being caught. When the Volume Target for the test rows is reached, the test will stop. Pour together or add together the amount caught in all the rows tested. Enter this amount in **Actual Volume (1)**.

Repeat the catch test to verify consistency and accuracy. Note: catch tests with water, especially if the system is operating at a low pressure, may not give an accurate catch test.

SurePoint electromagnetic flowmeters are typically very accurate out of the box with the factory flow cal. With accurate tests and measurements it is possible to calibrate them to 1 to 2% accuracy. A short test on a few rows with a small sample caught may not be accurate enough to adjust the flow cal. Always verify the flow cal in the field by comparing acres worked and gallons applied.

Best practices dictate ongoing verification of acres worked and gallons applied to verify flow cal.

A catch test can be done with water, but for the most accurate results, use the actual product.

Flow Cal for the actual product may be slightly different than the flow cal for water.

Product 1
Catch Test

Enable the Master Switch to begin the test. Disable the Master Switch to cancel and abort the test. Once the test is complete, press the Next button.

TOGGLE MASTER

Target/Actual Rate: 6.0 / 0.0 GPA
Pressure: 12.2 PSI
Flow Per Minute: 0.0 GPM
Volume Target/Actual: 128 / 128 OZ

Cancel Next

11:13am

Product 1
Catch Test

WARNING!! For an accurate sample make sure that the lines and pump are primed, the different rows sampled catch relatively the same amount and the system pressure is adequate. After changing the flow cal, run another test to verify the setting. Always verify with the area and amount of product used in the field after a calibration change.

Total the amount caught across all the rows. Put the sum of the amount caught in the 'Actual Volume' entry point. The new Proposed Cal will calculate. Press the Accept New Cal button change the calibration.

Expected Volume: 128.03 OZ
Actual Volume: **1** 130.00 OZ
Current Cal: 2500
Proposed Cal: 2462

Cancel Accept New Cal

11:13am





Customizable Toolbar & Totalizer Counters - Acres - Hours - Gallons

D

Setup & Operation

Sentinel has 3 totalizer counters to keep track of acres, hours, and gallons.

Any of these may be set up on the Customizable Toolbar near the top of the Product Run Screen. If these are not on the Customizable Toolbar, the values may still be seen by pressing the *Reset Totals* button on the Rate Setup screen. The items may be individually reset to 0 by pressing the Reset Total button for that item, or the totals may be left unchanged by returning to the Run Screen without resetting the values.



Push any of the **Reset** buttons to reset that total to 0.

To return without changing any of the totals, press **Done**.

Sentinel Rate Control Operation

D

Setup & Operation

Once the Sentinel has been set up in the display, little is required of the user to operate the Sentinel. The system can be started with an Implement Switch that will turn the system on when the implement is lowered. It can be turned on and off with a Master On/Off Switch (footswitch or on-screen). The system can also be turned on and off using Task Control to turn the system (or sections) on and off as the implement enters the field or overlaps previously applied areas using GPS location information.



Sentinel Wheat (Home) Button

On the HOME screen, the **top row (1)** is a Customizable Toolbar with options to display several different system parameters.

The **center section (2)** shows the Rate Control operation for each product. The user defined rates are available for selection on the go.

Center Section - If operating more than one product, the Target and Actual Rate for each product will be shown on the left side.

The **bottom section (3)** has 3 tabs. Watching the information on the Diagnostic tab will help the user become familiar with normal operating parameters. Knowing what is normal can help the operator diagnose and fix the issue if a problem occurs.

Normal operation is with Duty Cycle and Section Control set to AUTO.

To run, there must be SPEED, Height Switch down, Master ON, Product ON, target rate set, and a working width.

Toggle between Rate 1, 2, and 3 on the go, or press the top Target Rate box and enter a different target. Press the gear/teardrop on the bottom right to go to the Rate Setup screen.



To operate manually, press **Speed**, enter a speed, select **DUTY CYCLE MAN**, enter a DC% (minimum of 15 for electric, minimum of 30 for hydraulic),

Section Control: MAN. Master: ON.


Height switch: DOWN (if used)

To test the system, you can change the Duty Cycle % as the pump is running. Observe the Flow (GPM) and Pressure with each Duty Cycle %. On an electric pump system, you can do this with one pump plugged in at a time to verify the operation of each pump. Look at the *Diagnostic* tab on the *Operate / Setup / Diagnostics* section for more information.


Sentinel HOME Screen for Rate Control



MANUAL Operation



Setup values are shown for typical **hydraulic** pump system. These can be adjusted as necessary for best operation.



The screenshot shows the 'Setup' menu of a motor control system. The menu is organized into three main sections: 'Operate', 'Setup', and 'Diagnostic'. The 'Setup' section is currently active and contains several configuration parameters:

- Ctrl Mode:** A dropdown menu showing 'Rate'.
- Ctrl Speed:** A numeric input field set to '2000-2500'.
- RPM Cal:** A numeric input field set to '15'.
- Max RPM:** A numeric input field set to '500'.
- Flow Cal:** A numeric input field set to '3000'.
- PWM Max:** A numeric input field set to '100.00'.
- PWM Min:** A numeric input field set to '10.00'.
- Start Boost:** A numeric input field set to '0.00'.
- Open PWM:** A toggle switch currently in the 'Off' position (white).
- Open PWM Value:** A numeric input field set to '0.00'.

The 'Operate' and 'Diagnostic' sections are visible but not currently active.

Start Boost - 0 (pump starts where it stopped) or set in field (enter PWM DC % for startup speed)

Diagnostic is a screen that can be seen while operating in the field or while testing. The important system parameters can be seen here.

Operate		Setup		Diagnostic	
Duty Cycle	39.77	%			
Pressure	27.4	PSI			
Actual Flow	5.0	GPA	1.2	GPM	
Flow Freq	60.32	hz			
RPM	0.0				
RPM Freq	0.00	hz			
Working Width	20.0	ft			

MASTER
ON

Increased Duty Cycle with no increase in RPM could mean the pump is not getting enough hydraulic flow to spin the pump faster.

Diagnostic: (PWM) **Duty Cycle** shows the PWM signal sent from the controller to control the pump. On a hydraulic system, this needs to be around 30% before the pump will run. 40%- 50% is a typical operating range. On a normal pass this should be fairly stable ($\pm 2\%$). The Duty Cycle will adjust for speed, rate changes or width changes (sections going on and off).

Actual Flow shows the GPA being applied based on the Speed and the Machine Width.

Flow is the GPM measured by the flowmeter.

Flow Freq shows the number of pulses per second (hz) being received from the flowmeter. This should be fairly stable (± 2). When diagnosing flowmeter issues, watch this number during a tap test to see if the signal gets from the flowmeter harness connector to the display.

RPM shows the pump RPM on a hydraulic pump equipped with an RPM sensor. This should be less than 500. Can be set at 550 if maximum pump output is required. **RPM Freq** shows the signals received from the RPM sensor. This can also be used during a tap test on the Pump RPM harness connector.

Watch these values regularly during operation so you know what “normal” looks like. For example, a plugged strainer could mean the pump has to run faster than normal to get enough product. This will show up in an increased Duty Cycle and RPM.

Working Width will change as sections turn on and off. It should show the application width at any time.

Flow Cal can be adjusted slightly if an accurate catch test or field verification indicates it should. Increase Flow Cal if more product is needed. Decrease flow cal if less product is needed.

Decrease **PWM Min** if pump will not slow down enough for low speed/rate/width.

Check the **Diagnostic** screen regularly so you have an idea what “normal” operating numbers are. This can help when you need to troubleshoot an issue.

MASTER ON

SPEED
6.0
MPH

ACTUAL PRESS
27.4
PSI

FLOW
1.2
GPM

DUTY CYCLE
39.77
%

Manual Section

5.0 GPA **5.0** **5.0 GPA** **0.0**

5.00 **5.00** **7.00** **9.00**

DUTY CYCLE
39.77 %

SECTION CONTROL

Operate **Setup** **Diagnostics**

Duty Cycle 39.77 %
Pressure 27.4 PSI
Actual Flow 5.0 GPA 1.2 GPM
Flow Freq 60.32 hz
RPM 0.0
RPM Freq 0.00 hz
Working Width 20.0 ft

MASTER ON

SurePoint Ag Systems



Setting Up a System With Sentinel Rate Control and Sentinel Row Flow Monitoring



226-01-3547Y1
Sentinel ISOBUS ECU

Typically will use one of the following Sentinel ECU Harnesses

For Rate Control **without Gen 3 LiquiShift**

208-06-5022Y1	Sentinel Row Control and Flow Monitoring ECU Harness- 2 products - 18 sections
208-06-4099Y4	Sentinel Row Control and Flow Monitoring ECU Harness - 2 products - 18 sections
208-06-4984Y2	Sentinel Row Control and Flow Monitoring ECU Harness - 4 products - 18 sections

For Rate Control **with Gen 3 LiquiShift**

208-06-5023Y1	Sentinel Row Control and Flow Monitoring ECU Harness - Gen 3 LiquiShift - 2 PR - 16 sect
208-06-4701Y2	Sentinel Row Control and Flow Monitoring ECU Harness - Gen 3 LiquiShift - 2 PR - 16 sect
208-06-4985Y1	Sentinel Row Control and Flow Monitoring ECU Harness - Gen 3 LiquiShift - 4 PR - 16 sect

Sentinel Setup and Configuration









Set-up and Configuration for Rate Control & Row Monitoring

D
Setup &
Operation

The following pages will guide you through the initial set-up and configuration of your Sentinel Rate Control & Row Monitoring system. Below is an overview of the steps necessary to fully configure the system before operation. Each subsequent page outlines the page features as well as the sequence of buttons used to navigate to that page from the HOME screen.

Basic Steps for Initial System Set-up for Rate Control & Row Monitoring

For detailed information on a step, go to the referenced page

REFERENCE Page #	STEP	
67	1. Press the HOME button	
67	2. Go to the settings page by touching the SETTINGS button	
67	3. On the settings page, specify the number of products being monitored (maximum of 4)	
67-68	4. Configure each product by touching the PRODUCT button	
67	5. Select DEVICE (<i>Liquid Rate Control + Monitor</i>) and set up each product (sections, rows,...)	
68	6. Press MORE , set up Rate (USER DEF), Smoothing (10%), other options for this setup.	
	7. When finished, use the BACK arrow to go back to the SETTINGS menu.	
69	8. Set up the implement dimensions by touching the IMPLEMENT button.	
69	9. Choose a speed source by selecting the SPEED button.	
69	10. Select system control options (task control, lift switch, etc.) under HARDWARE .	
70(68)	11. Select the Rate Mode (<i>USER DEF</i>) at RATE SETUP .	
70-71	12. From the Settings screen, touch the NEXT button.	
71	13. Click on Flow Module Diagnostics	
71	14. Ensure that all flow modules are plugged in and click Reset All Addresses	
	15. Unplug all of the Sentinel Flowmeter Modules.	
	16. Beginning with module #1 (on Product 1), plug it back in - module 1 should turn green on the screen. Have someone watch the screen to verify successful addressing for each module.	
	17. Moving across the implement, plug in each module for Product 1 in order.	
	18. If applicable, address the modules for product 2 by repeating steps 15-17 for Product 2.	
	19. Select the correct module orientation (ABCD or DCBA) (What is Row 1? (A) or (D)?)	
72	20. Customizing Scans and Alarms	

Sentinel Setup and Configuration

Set-up and Configuration for Rate Control & Row Monitoring



The following pages will guide you through the initial set-up and configuration of your Sentinel Rate Control & Row Monitoring system. Below is an overview of the steps necessary to fully configure the system before operation. Each subsequent page outlines the page features as well as the sequence of buttons used to navigate to that page from the HOME screen.

Basic Steps for Initial System Set-up for Rate Control & Row Monitoring

For detailed information on a step, go to the referenced page

REFERENCE Page #	STEP
73	21. Setup settings for Rate Control - Control Speed, RPM Cal, Flow Cal, PWM Max and Min
73	22. Software Version and Auxiliary Settings Screens
74	23. LiquiShift Setup
75	24. Row Detail Screen, Enable/Disable Row, Flow Adj for row
76	25. Customizable Toolbar and Totalizer Counters
77-79	26. Rate Control & Row Monitoring Run Screen and Operation & Setup Summary
80	27. Nozzle Test - Simulated speed and rate test
81-82	28. Catch Test - Verify and adjust flowmeter calibration
83	29. Fine-Tuning Sentinel Row Flow Monitoring

Sentinel Setup and Configuration

Home Screen Navigation for Rate Control

D

Setup & Operation

Sentinel Home Screen for Rate Control.

Identifies this screen as showing Product 2.

If an implement height switch is plugged into the Sentinel harnessing, there is an arrow showing the current implement height status.




Target and Actual Rate shown. Green buttons indicate product is ON.

Operate, Setup, & Diagnostic tabs for Rate Control setup, operation, and troubleshooting diagnostics.

BUTTONS: Wheat & Row Bar



The wheat button takes you to the Rate Control RUN SCREEN (below). This button appears on the top right side of the screen. Pressing it puts the Rate Control information in the center section (see above).



Press the Row Bar Graph button or the Wheat button in the bottom left corner to toggle between the two screens on the bottom third.

Customizable Toolbar (Screen Settings)




Touching this gear button will allow you to set up the icons on this **Customizable Toolbar** row of the screen. When you press this button you will see three rows of icons. The top row shows what is on your screen now. To change an icon, press on that icon on the top row and then press on the icon you want there on the 2nd or 3rd row. Click OK.



Toggle between product screens by touching the **NEXT PRODUCT** button.



The **SETTINGS TOOLS** button will be used to access the system configuration pages for Product setup and to change individual product alarm, tolerance, and rate settings.



The **MASTER ON/OFF** button enables and disables the Sentinel system. This must be **GREEN (MASTER ON)** for Sentinel to work.

ARROW indicates implement position when using Implement Switch with Sentinel



SETUP for Rate Control with Row Monitoring- Product Setup - Rate Mode Setup - LiquiShift Enable

D

Setup & Operation

Product 1
1-Product 1

Device: LiqMon+Cont **7** Sections: 16 **8** Total Rows: 16 **9** Spacing: 30.0 Inch

Start Row: 1 **10** Implement Width: 40.0 FT **11** Tolerance: 25.0 % **12**

	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	1	13	1		
2	1		1		
3	1		1		
4	1	16	1		
5	1				
6	1				
7	1				
8	1				
9	1				
10	1				
11	1				
12	1				

Start Section: 1 **14a** Metric Units: ☐ **14b** More

- 7.) Enter the number of **SECTIONS** for this product. *See note at bottom of p.70 for Gen3.
- 8.) Enter the number of **ROWS** for this product.
- 9.) Enter the row spacing in **INCHES**.
- 10.) **Start Row** = 1 for Product 1.
Product 2 Start Row will typically be 1 more than the number of rows on Product 1.
- 11.) Enter **Implement Width** in FT.
- 12.) **Tolerance** - start at 25%. This is for Row Monitoring. Bar will turn red if a row varies by more than this from the average flow.
- 13.) Verify the number of rows in each section.
- 14a.) Check this box for **Metric Units**.
- 14b.) Press **More** to go to the next screen.

- 15.) See below: **Rate Mode** - For rate control, set this to **Rx** (for prescriptions) or to **User Def** to enter preset rates. Enter the main target rate in **Rate**.

Product 1
1-Product 1

Rate Mode: User Def **15** Rate: 6.00 **16** Rate Smooth: 10 % ☒ **22**

Row Smooth: 10 % ☒ **17**

User Defined Manual Rates: 6.00 7.00 8.00 **18**

Outside Row Rates: First X 1.0 Last X 1.0 **19**


Control Integral (K1): 0.10 **20**

LiquiShift Enable: ☒ **21**

LiquiShift A/B Close On Stop: ☐ **22**

- 16.) **Rate Smooth** - Start with 10%. If the actual Rate at any time is within this % of the Target Rate, the display will show the Actual Rate as being equal to the Target Rate.
- Row Smooth - 10%** The bar graph will show a thin green line for each row that is within this % of the target.
- 17.) You can enter up to 3 user-defined rates.
- 18.) **Rate for Outside Rows** is typically "X 1.0".
Some applications may be "X 0.5" (half-rate) or "X 1.5" (rate and a half) for outside rows.
- 19.) **Control Integral** - 0.10
- 20.) **LiquiShift Enable** - Check this box if Sentinel is controlling LiquiShift on this product (typical if using LiquiShift). (LiquiShift A-B valves can be controlled by a black LiquiShift Control Module on the back of the A-B Valve stack or can be controlled by the Sentinel.)
- 21.) **LiquiShift A/B Close on Stop** - Typically this is not checked.
- 22.) Press the **Back Arrow** when finished with this screen.

SETUP for Rate Control and Row Flow Monitoring - Implement - Speed - Hardware




24.) Press **Implement** to enter and verify the Implement geometry.

The Implement dimensions are used when Task Control is enabled. Task Control is normally enabled for Rate Control. Task Control is needed for Section Control and Mapping.

A = distance from Hitch to implement pivot (axle)
B = implement offset (left or right)
C = distance from Implement pivot (axle) to application point
(This combines with the geometry set up in the controller for the position of the GPS in relation to the hitch)


Press the Back Arrow when finished.



25.) On the right side, Press **Speed**.

Press the top box to select the Speed Source. This is typically Ground Speed.

26.) Look at this box while moving to see which speed sources are reporting.



27.) On the right side, press **Hardware**.

28.) **Use Master Switch** - check this box if a dedicated Master Switch (Foot Switch) is plugged into Sentinel. Quite often used for Rate Control.

29.) **Use Height Switch** - Check this only if the Sentinel has a dedicated height switch. Quite often used for Rate Control.

30.) **Setup** - to set up a height sensor or to change orientation of switch.

31.) **Enable Task Control** - normally used for Rate Control. Also, must activate Task Control on display.

32.) **Enable IntelliSection Technology** - not usually used for Rate Control when Task Control is used.



SETUP for Rate Control & Row Flow Monitoring - Rate Setup - Flow Adjustment - 2 Products

33.) For Rate Control verify the Setting is Rx or User Def. Smoothing usually starts at 10%. Use Presets to enter up to 3 rates.



34.) **Flow Adjustment** - Use this to synchronize the Sentinel flowmeter modules with the main system flowmeter. Once the accuracy of the main flowmeter has been confirmed, change the Flow Adjustment factor as needed to synchronize the Sentinel reading with the main flowmeter reading.

$$\frac{\text{Main Flowmeter GPM}}{\text{Sentinel Total Flow GPM}} =$$

Flow Adjustment Factor

(Generally, will be between 0.95 and 1.05.)

On software version 1.3.0 and later, the Flow Adjustment factor can be set for each row on the Row Detail Screen if an individual row is reading incorrectly (see page 75).

SETUP for 2 products with Rate Control and Row Flow Monitoring

If you are setting up Sentinel to do rate control and row monitoring on 2 products your screen will look like this. You will need to go through the setup steps for both Product 1 and Product 2.

Product 2 will usually start with the next row after Product 1, so if Product 1 has 8 rows, Product 2 will start with Row 9.

Product 2 may start with Section 7 if the main harness has connectors for Sections 1-6 and Sections 7-12 on a non-Gen3 LiquiShift system.

***Gen3 LiquiShift** systems may have different section setups. Check the section harness to see which section the last row is assigned to in order to determine total number of sections for each product.

12 rows	12 sections	} <i>One product</i>	Gen3 LiquiShift	} <i>Two Products</i>	12 rows	6 sections
16 rows	16 sections				16 rows	8 sections
24 rows	12 sections				24 rows	8 sections

Sentinel Flow Module Setup and Configuration

Addressing Sentinel Flow Modules

D

Setup &
Operation



Flow Module Diagnostics


To address the Sentinel flow modules, start by having all the modules plugged in. From this screen, push **Reset All Addresses**. This sends a message to the modules to erase their address. All modules for Product 1 are then unplugged and then plugged back in, in order across the machine. As each module is plugged in, Sentinel identifies its location on the machine and the module is then given its new address and it will turn green on the screen. *Have someone watch this screen to be sure each module is recognized as it is plugged in.*

If there is a problem with modules not addressing, be sure the tractor is running to keep the voltage up.


Once all modules are addressed, choose the proper **orientation** as described below.

Repeat for each Product.

Flow Module Diagnostics Screen




OR




Most machines will have the modules mounted facing forward, causing Row 1 to correspond with row D on the module. Therefore, the orientation DCBA must be selected. Likewise, if the modules are mounted rear-facing, the orientation ABCD will be selected.



Press the toggle button to go to the next page of modules if needed.



Example 16-Row—D C B A Orientation




Customizing Scans & Alarms for Row Monitoring



This screen allows the user to change how row information is displayed on the HOME screen.

- 35.) When checked, the **Auto Scan** feature will scan through the product pages and/or rows on the HOME screen. You can change the length of time it stays on each page or row before advancing.
- 36.) **Auto Hide Alarms (if checked)** sets how long full-page alarms are displayed before they go away.
- 37.) **Disable Alarms** - Check this to turn off alarms. May want to do this for testing or troubleshooting.
- 38.) **Alarm Time** - how long a row must be outside of the specified tolerance before the alarm sounds.
- 39. **Re Alarm Interval** - The time before the Alarm alarms again after being acknowledged. If the issue that triggered the alarm is not resolved, it will keep alarming at this interval until resolved (if the box is checked).
- 40. **Bus Update Interval** - Use this to slow down ISOBUS traffic if the BUS load is too high. *Reset only after talking to a SurePoint representative.*
- 41.) **Flow Module Diagnostics** - Flow Module Diagnostics are addressed on previous page.
- 42.) **Store Object Pool** - Stores the current ISOBUS layout on the VT.
- 43.) **Delete Object Pool** - Deletes the current object pool on the VT and forces the monitor to regenerate the display when it is rebooted.
- 44.) **Next VT** - press to push Sentinel to another virtual terminal. This may be necessary if there is more than one monitor or display in the cab.



Next VT icon from v.1.3.0



Save to this VT from v.1.3.0



SENTINEL

1-Product 1

MASTER OFF

SPEED

0.0

MPH

ACTUAL PRESS

0.1

PSI

FLOW

0.0

GPM

DUTY CYCLE

0.00

%

Manual Section

GPA

5.0

0.0

DUTY CYCLE

Rate 1

5.00

Rate 2

10.00

Rate 3

15.00

SECTION CONTROL

Operate

Setup

Diagnostic

Ctrl Mode

Rate

Ctrl Speed

200.00

RPM Cal

15

Max RPM

500

Flow Cal

2000

PWM Max

80.00

%

PWM Min

25.00

%

Start Boost

0.00

%

Open PWM

0.00

%

The image shows a yellow background with a large, faint '4' watermark. In the top left, there is a logo consisting of a blue and orange sphere with a black square containing a red '4' and a sunburst. To the right of the logo is the 'SureFire' brand name in a stylized blue font with a red underline. Below the logo, the text 'Sentinel ECU Version:' is displayed, followed by 'V.1.3.0'. Further down, 'Sentinel ECU Serial #:' is shown, followed by '356400'. At the bottom, a long alphanumeric string '0U812000000000000000000000BR549' is displayed, followed by 'A00A80005D40000A' and '00000000000000A000'. On the right side, there is a vertical strip of icons: a small logo at the top, a green plant icon, and several empty rectangular boxes. At the bottom right, there is a small 'SureFire' logo.

Sentinel Rate Control and SurePoint LiquiShift

SurePoint LiquiShift can be controlled through the Sentinel ECU or through a LiquiShift Controller Module (black box-PN 218-2565Y1). Most times, Sentinel will be used to control **Gen3 LiquiShift**, and the LiquiShift Controller Module is not needed. To activate LiquiShift on Sentinel, follow these buttons:




The LiquiShift button will now be displayed on the HOME screen

Gen2 LiquiShift: If the LiquiShift Controller module (218-2565Y1) is mounted on the back side of the A-B LiquiShift valves, the 8-pin LS Controller connector on the Sentinel ECU harness will be plugged into the connector from the black box.

If this module is not there, an 8-pin harness extension (206-08-XXXX) is added from the Sentinel ECU harness (LS Controller connector) to the LiquiShift Controller plug on the Manifold Controller (3454) harness.


The Sentinel gives the operator absolute control over the LiquiShift shift points, real-time pressure readings, and provides in-cab manual control. For more information regarding the use of Sentinel in controlling your SurePoint LiquiShift, refer to your LiquiShift system manual.



Setting LiquiShift shift points



Standard High Pressure Up Shift Point: 70 PSI



Standard Low Pressure Down Shift Point: 20 PSI

If these shift points are not set correctly, the LiquiShift may not work or may work very erratically.

They must be set so that when the valves switch, there is appropriate pressure in the new tube to keep the system operating smoothly.

For example, if the shift points are set at 50 PSI and 25 PSI, the valves will switch from A to B when the pressure in tube A reaches 50 PSI. This flow in tube B may only build 15 PSI, so it will immediately switch back to A. Since the pressure there is 50 PSI or more, it will switch to B. The system will switch back and forth repeatedly causing wild pressure rate and pressure fluctuations.

There may be situations where it may work better to use something other than a 70/20 PSI setpoint, but don't set other numbers without knowing what you are doing.



For typical operation, this box is NOT checked.




Switch to MAN to control A & B valve from this screen



Green - Valve is ON.

Row Bar Graph and Row Detail Screen



- 1.) Pressing the Row Detail button (bottom right corner) on the Run screen brings up the Row Detail Screen (bottom screenshot).

The bar graph for Rows 1-16 shows the flow in each row at that instant.

A thin green line means the flow varies less than the Smoothing Factor % from the correct amount.

A thicker green line means the flow on that row varies by more than the Smoothing Factor % but less than the Tolerance %.

A red bar indicates the flow on that row varies by more than the Tolerance % set up for that product.

Example: Smoothing Factor - 10%

Tolerance - 20%

Flow less than 10% variance - thin green line

Flow with 10-19% variance - thicker green band

Flow more than 20% variance - red band

Press *Pause Row Scan* at the top.

- 2.) Press the Left Arrow or Right Arrow to see details for other rows.
- 3.) A Row can be ENABLED or DISABLED by checking or unchecking the **ENABLED** box.
- 4.) **Flow Adj.:** If a catch test confirms that the actual flow in the row is more or less than what the Sentinel shows for that row, adjust the individual row flowmeter calibration here. Usually will be between 0.95 and 1.05. Adjust as needed per catch test verification.





Customizable Toolbar & Totalizer Counters - Acres - Hours - Gallons

D

Setup & Operation

Sentinel has 3 totalizer counters to keep track of acres, hours, and gallons.

Any of these may be set up on the Customizable Toolbar near the top of the Product Run Screen. If these are not on the Customizable Toolbar, the values may still be seen by pressing the *Reset Totals* button on the Rate Setup screen. The items may be individually reset to 0 by pressing the Reset Total button for that item, or the totals may be left unchanged by returning to the Run Screen without resetting the values.



Push any of the **Reset** buttons to reset that total to 0.


To return without changing any of the totals, press **Done**.

Sentinel Rate Control & Row Monitoring Operation

D


Setup & Operation

1.) When operating with RATE CONTROL and ROW FLOW MONITORING, the Wheat button in the **top right corner** gives you the top half of the screens below.



- (2) and (3) Button in lower left corner is a toggle switch.
- 2) Press to bring up Row Bar View. (Must be on Operate tab to have toggle button.)
- 3) Press to bring up Operate/Setup/Diagnostic tabs

Typical Run Screen view for Rate Control & Row Monitoring Operation



Sentinel Rate Control Operation

D

Setup & Operation

Once the Sentinel has been set up in the display, little is required of the user to operate the Sentinel. The system can be started with an Implement Switch that will turn the system on when the implement is lowered. It can be turned on and off with a Master On/Off Switch (footswitch or on-screen). The system can also be turned on and off using Task Control to turn the system (or sections) on and off as the implement enters the field or overlaps previously applied areas using GPS location information.



Sentinel Wheat (Home) Button

On the HOME screen, the top row is a Customizable Toolbar with options to display several different system parameters.

The center section shows the Rate Control operation for each product. The user defined rates are available for selection on the go.

The bottom section has 2 possible screens. It will be the *Operate/Setup/Diagnostic Tabs* or the *Row Bar Graph*. Watching the information on the Diagnostic tab will help the user become familiar with normal operating parameters. Knowing what is normal can help the operator diagnose and fix the issue if a problem occurs.

Center Section - If operating more than one product, all products will be shown on the left side of this section.

Normal operation is with Duty Cycle and Section Control set to AUTO.

To run, there must be SPEED, Height Switch down, Master ON, Product switch ON (green), target rate set, and a working width.

Toggle between Rate 1, 2, and 3 on the go, or press the top Target Rate box and enter a different target. Press the gear/teardrop on the bottom right to go to the Rate Setup screen.

To operate manually, press **Speed**, enter a speed, select **DUTY CYCLE MAN**, enter a DC% (minimum of 15 for electric, minimum of 30 for hydraulic),




Section Control: MAN. Master: ON.

Height switch: DOWN (if used)

Product switch : ON (green)

To test the system, you can change the Duty Cycle % as the pump is running. Observe the Flow (GPM) and Pressure with each Duty Cycle %. On an electric pump system, you can do this with one pump plugged in at a time to verify the operation of each pump. Look at the *Diagnostic* tab for more information.

Sentinel HOME Screen for Rate Control



Sentinel HOME Screen for Rate Control -- Setup and Diagnostic Tabs

Setup values are shown for typical **electric** pump system. These can be adjusted as necessary for best operation.

Setup values are shown for typical **hydraulic** pump system. These can be adjusted as necessary for best operation.

Operate		Setup		Diagnostic	
Ctrl Mode	Rate	PWM Max	100.00 %		
Ctrl Speed	2000-2500	PWM Min	10.00 %		
RPM Cal	15	Start Boost	0.00 %		
Max RPM	500	Open PWM	0.00 %		
Flow Cal	3000	ELECTRIC			

Operate		Setup		Diagnostic	
Ctrl Mode	Rate	PWM Max	80.00 %		
Ctrl Speed	Pg.54	PWM Min	20 - 30 %		
RPM Cal	15	Start Boost	0.00 %		
Max RPM	500	Open PWM	0.00 %		
Flow Cal	2000	HYDRAULIC			

Ctrl Speed: Decrease if pump surges or oscillates back and forth above and below the rate. Increase if pump is slow to adjust. See page 54 for hydraulic pump settings.

RPM is not used with electric pumps.

Start Boost - 0 (pump starts where it stopped) or set in field (enter PWM DC % for startup speed)

Diagnostic is a screen that can be seen while operating in the field or while testing. The important system parameters can be seen here.

Flow Cal can be adjusted slightly if an accurate catch test or field verification indicates it should. Increase Flow Cal if more product is needed. Decrease flow cal if less product is needed.

Decrease **PWM Min** if pump will not slow down enough for low speed/rate/width.

Check the **Diagnostic** screen regularly so you have an idea what "normal" operating numbers are. This can help when you need to troubleshoot an issue.

Operate		Setup		Diagnostic	
Duty Cycle	39.77 %				
Pressure	27.4 PSI				
Actual Flow	5.0 GPA	1.2	GPM		
Flow Freq	60.32 hz				
RPM	0.0				
RPM Freq	0.00 hz				
Working Width	20.0 ft				

Operate		Setup		Diagnostic	
MASTER ON	SPEED 6.0 MPH	ACTUAL PRESS 27.4 PSI	FLOW 1.2 GPM	DUTY CYCLE 39.77 %	Manual Section
5.0 GPA	5.0	5.00 GPA	5.00	Rate 1 5.00	Rate 2 7.00
5.0 GPA	0.0	5.00 GPA	5.00	Rate 3 9.00	Rate 4 11.00
				DUTY CYCLE 39.77 %	
				SECTION CONTROL	

Diagnostic Tip: Note the relationship between Duty Cycle (%), Pressure, Flow (GPM), and RPM (hydraulic pump). If Duty Cycle and RPM increase above what is normal for a given flow, there could be a restriction on the inlet side of the pump. This could be a plugged strainer or a strainer that gets gelled over, especially with cold fertilizer.

Increased Duty Cycle with no increase in RPM could mean the pump is not getting enough hydraulic flow to spin the pump faster.

Diagnostic: (PWM) Duty Cycle shows the PWM signal sent from the controller to control the pump. On a hydraulic system, this needs to be around 30% before the pump will run. 40%- 50% is a typical operating range. On a normal pass this should be fairly stable ($\pm 2\%$). The Duty Cycle will adjust for speed, rate changes or width changes (sections going on and off).

Actual Flow shows the GPA being applied based on the Speed and the Machine Width.

Flow is the GPM measured by the flowmeter.

Flow Freq shows the number of pulses per second (hz) being received from the flowmeter. This should be fairly stable (± 2). When diagnosing flowmeter issues, watch this number during a tap test to see if the signal gets from the flowmeter harness connector to the display.

RPM shows the pump RPM on a hydraulic pump equipped with an RPM sensor. This should be less than 500.

Can be set at 550 if maximum pump output is required. **RPM Freq** shows the signals received from the RPM sensor. This can also be used during a tap test on the Pump RPM harness connector.

Watch these values regularly during operation so you know what "normal" looks like. For example, a plugged strainer could mean the pump has to run faster than normal to get enough product. This will show up in an increased Duty Cycle and RPM.

Working Width will change as sections turn on and off. It should show the application width at any time.

TESTS - Nozzle Test (v 1.3.0 and later)

Test run the system with a simulated speed and target rate.

From the Product Setup page press the Nozzle Test icon (35). Be sure MASTER is OFF. Press NEXT.



Product 1

1-Product 1

Device

Sections

Total Rows

Spacing

LiqRowCont

16

16

30.0 Inch

Start Row

Implement Width

Tolerance

1

40.0 FT

25.0 %

Sec#	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	1	13	1		
2	1	14	1		
3	1	15	1		
4	1	16	1		
5	1				
6	1				
7	1				
8	1				
9	1				
10	1				
11	1				
12	1				

Metric Units

35

More

14:00

Product 1

Nozzle Test

Ensure Master Switch is OFF to proceed with test.

MASTER OFF

Next

14:01

Select which sections you want to run for this test. NEXT.

Enter SPEED and RATE. NEXT.

Product 1

Select Sections to run for Test

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

Prev

Next

14:01

Product 1

Nozzle Test

For the nozzle test, the system will run the previously selected sections at a specified rate. Please enter the information below.

Simulated Speed:

5.0 MPH

Target Rate:

10.0 GPA

Prev

Next

14:01

Turn MASTER ON to start the test. **Monitor Actual Rate, Pressure, Flow per Minute, Duty Cycle (%), and Pump RPM (hydraulic pump). These are important parameters of system operation. Know what they are during normal operation.**

Product 1

Nozzle Test

Enable the Master Switch to begin the test. Disable the Master Switch to abort the test.

MASTER ON

Target/Actual Rate

10.0 / 10.0 GPA

Pressure:

21.9 PSI

Flow Per Minute:

2.0 GPM

Duty Cycle:

25.75 %

Pump RPM:

0.0

Cancel

10:16am

To stop the test, turn MASTER OFF.

If only 1 or 2 rows are on, the system may struggle to maintain a smooth output and rate.

When testing with water, the pressure will be much less than it will be with a heavier, thicker fertilizer. On a system with check valves, some of the check valves may not open at low pressure.

Increase the speed or rate to increase the pressure.

SETUP for Rate Control - TESTS - Catch Test (v 1.3.0 and later)

Verify and adjust the flowmeter calibration.



From the Product Setup page press the Catch Test icon (36). Be sure MASTER is OFF. Press CATCH TEST (37).

Product 2

2-Product 2

Device: **BigRateCont** Sections: **2** Total Rows: **16** Spacing: **30.0** Inch

Start Section: **17** Implement Width: **40.0** FT Tolerance: **25.0** %

Sec#	Num Rows	Sec#	Num Rows	Sec#	Num Rows
1	8				
2	8				

36

11:21

Metric Units

Product 2

Catch Test 37

WARNING!!! For an accurate sample make sure that the lines and pump are primed, the different rows sampled catch relatively the same amount and the system pressure is adequate. After changing the flow cal, run another test to verify the setting. Always verify with the area and amount of product used in the field after a calibration change.

If an expected and known volume is already known, enter the information below

Expected Volume: **0.00**
Actual Volume: **0.00**
Current Cal: **600**
Proposed Cal: **600**

Accept New Cal

11:21

Product 2

Catch Test

Ensure Master Switch is OFF to proceed with test.

MASTER OFF

Next

11:22

Product 2

Select Sections to run for Test

1 2

Select which sections you want to run during the test or run with all sections ON.

Next

11:22

Product 1

Catch Test

For the catch test, the system will run the previously selected sections until a specified volume is reached. Please enter the information below.

Enter the information. For better results catch more rows, catch a larger volume, and let the test run longer.

Number Of Rows To Catch: **8**
Simulated Speed: **5.0** MPH
Target Rate: **8.0** GPA
Volume to Dispense Per Row: **16** OZ

Next

11:12am

Product 1

Catch Test

Enable the Master Switch to begin the test. Disable the Master Switch to cancel and abort the test. Once the test is complete, press the Next button.

MASTER ON

Target/Actual Rate: **8.0 / 8.0** GPA
Pressure: **14.8** PSI
Flow Per Minute: **1.6** GPM
Volume Target/Actual: **128 / 54** OZ

The Volume Target is the volume per row multiplied by the number of rows being caught.

Cancel **Next**

11:12am

SETUP for Rate Control - TESTS - Catch Test (v 1.3.0 and later)

Verify and adjust the flowmeter calibration.

While the test is running, the actual rate, pressure, and GPM will be shown. The Volume Target is the volume per row multiplied by the number of rows being caught. When the Volume Target for the test rows is reached, the test will stop. Pour together or add together the amount caught in all the rows tested. Enter this amount in **Actual Volume (1)**.

Repeat the catch test to verify consistency and accuracy. Note: catch tests with water, especially if the system is operating at a low pressure, may not give an accurate catch test.

SurePoint electromagnetic flowmeters are typically very accurate out of the box with the factory flow cal. With accurate tests and measurements it is possible to calibrate them to 1 to 2% accuracy. A short test on a few rows with a small sample caught may not be accurate enough to adjust the flow cal. Always verify the flow cal in the field by comparing acres worked and gallons applied.

Best practices dictate ongoing verification of acres worked and gallons applied to verify flow cal.

A catch test can be done with water, but for the most accurate results, use the actual product.

Flow Cal for the actual product may be slightly different than the flow cal for water.

Product 1
Catch Test

Enable the Master Switch to begin the test.
Disable the Master Switch to cancel and abort the test. Once the test is complete, press the Next button.

TOGGLE MASTER

Target/Actual Rate: 6.0 / 0.0 GPA
Pressure: 12.2 PSI
Flow Per Minute: 0.0 GPM
Volume Target/Actual: 128 / 128 OZ

Cancel Next

11:13am

Product 1
Catch Test

WARNING!! For an accurate sample make sure that the lines and pump are primed, the different rows sampled catch relatively the same amount and the system pressure is adequate. After changing the flow cal, run another test to verify the setting. Always verify with the area and amount of product used in the field after a calibration change.

Total the amount caught across all the rows. Put the sum of the amount caught in the 'Actual Volume' entry point. The new Proposed Cal will calculate. Press the Accept New Cal button change the calibration.

Expected Volume: 128.03 OZ
Actual Volume: **1** 130.00 OZ
Current Cal: 2500
Proposed Cal: 2462

Cancel Accept New Cal

11:13am

Fine-Tuning Sentinel Row Flow Monitoring


ISSUE: “My Sentinel does not show the same rate or flow as my rate controller.”

What’s happening: It’s possible that the flowmeter on the rate controller and the Sentinel row flowmeters are not in sync.

Do This: If you are applying 5.5 gal/acre with the rate controller, but the Sentinel shows 5.0 gal/acre (1), do a **catch test** with the regular flowmeter to determine if it is calibrated correctly. Adjust as needed.

Once the rate controller flowmeter is calibrated correctly, then compare the Rate (1) and the Flow (2) with what the Rate Controller shows. If there is a discrepancy, go to the Sentinel Rate Setup screen, and change the Flow Adj. factor.

If the Sentinel is showing too much flow, reduce the Flow Adj. If the Sentinel is reading low, increase the Flow Adj. (Start with 0.95 or 1.05 and fine-tune from there.)




ISSUE: “One row always shows high (or low) flow.”

First: What is the Row Smoothing set at? Recommended starting point is 10%. What is the Tolerance set at? We recommend starting at 25%. These can be adjusted either way.

What’s happening: Two possibilities:


- (1) That row is always applying high or low.
- (2) The row is applying correctly, but the Sentinel is reporting it as high (or low).



Do This: A. Swap hoses or tubes to switch rows at the Sentinel to see what the Sentinel shows. This may give an idea of where the problem is.

B. Do a **catch test** on that row and on a couple rows either side of it.

- (1) If the row is applying high (or low) check the plumbing to that row for any conditions that might be causing the error. If you can find nothing causing the discrepancy, you can increase the flow to a row by shortening a metering tube a few inches. You can decrease the flow to a row by putting a hose clamp around a hose to that row.
- (2) If the row is actually applying correctly, but showing wrong on the Sentinel, change the Flow Adj. on the Row Detail screen. If the Sentinel is reading low, increase the Flow Adj (1.05). If the Sentinel is showing high, decrease the Flow Adj (0.95).
- (3) Fine-tune the Flow Adj as needed.



Sentinel Troubleshooting

Sentinel doesn't show up on my display



1. Verify that the Sentinel ECU has power - 2 green lights should be illuminated on the ECU.
 - A. Using a voltage tester, check voltage on the ECU harness.
2. Do you have more than one display (VT)? Check to see if Sentinel booted up on the other display.
3. Check connections:
 - A. Tractor ISO plug
 - B. CAN and power connections leading to the ECU harness
4. Reboot everything.

Sentinel flow module(s) will not address

1. Be sure there is a terminator on the end of Flowmeter Bus 1 and Flowmeter Bus 2.
2. Make sure that the trunk lines are plugged into the correct port on the module (+12v DC).
3. Be sure the tractor is running. Low voltage may cause modules to not address.
3. Make sure that you have all the modules plugged in before touching **RESET ALL ADDRESSES**
4. Unplug ALL modules for that Product and plug the modules in one at a time, making sure the previous module addresses before moving on to the next (have someone watch the display and startup light sequence on the module (see page 30).
5. Verify that the lights on the module are flashing. If there are no lights, there is no power to the module.
 - A. If the module lights do not light up, check the connection to the module and inspect all connections to the ECU harness.
 - B. If all connections look good, use a voltmeter to check voltage to the module using the harness drawings.
 - C. If 12 volts is present and module fails to light up, the module may be faulty.
6. Reboot everything.

When addressing modules, one or more modules flash green or stay blue

1. Make sure that the implement is set up with the correct number of rows.
 - A. If a module is plugged in that the Sentinel is not expecting, it may flash blue/green to signify that it is addressed, but not expected. Not all ISO displays will respond this way.
2. If your implement is configured with a number of rows not divisible by 4, the last module may not show as "expected". For instance, in the case of a 6-row potato planter, 2 modules are used but only 2 rows are plumbed on the second module. When addressing, module 2 may display as "not expected." When plugged in, it will be issued an address and 6 rows will display on the Sentinel HOME screen. The last 2 rows on the module will be ignored.

Sentinel shows no flow and rows are grey

1. Make sure the **MASTER** button on the Sentinel **HOME** screen displays **MASTER ON**. If not, touch the button to cycle it. If there is a Height Switch arrow on the MASTER button, be sure it shows down to run.
2. Are you performing a stationary flow test? If so, a simulated speed must be entered and Section Control must be MAN.
3. Is a speed being displayed on the Sentinel **HOME** screen when moving?
 - A. If not, change the speed source.

Sentinel Row Flow Troubleshooting

E

Trouble-Shooting

Individual rows read high or low

1. Are you testing with water? Unless the system is designed for water, row-flow may be uneven. Some rows may not flow if there is not enough pressure.
 - A. Increase rate to build a minimum of 15 pounds of system pressure
2. Check row plumbing
 - A. Look for pinched or kinked lines to the row
 - B. Inspect check valves for plugging or damage
 - C. Clean out orifices and inspect placement (seed firmer, stainless tube, etc.) for plugging
 - D. Flip the outlet plumbing for 2 rows and determine if the problem follows the row
 1. If the low/high flow reading stays with the same row on the Sentinel, inspect the module for plugging.
 2. Flush the module with warm water and clean the inside of the flowmeter with soft brush/rag.
3. Row-flow may be too low for Sentinel to read or product may not be conductive
 - A. Increase rate or add a small amount of fertilizer to product to increase conductivity
4. Perform a catch test on several rows to determine if the information being displayed is correct.
5. Adjust the individual flowmeter with the **Flow Adj.** on the Row Detail screen.

NOTE: Water is not always a great conductor. If you are having problems reading flow with water, try adding a small amount of fertilizer to your product tank.

Sentinel alarms too often

Often times during initial start-up the Sentinel alarms can seem excessive as Sentinel highlights the row-to-row inaccuracies in the system. Small things like tubing lengths and check valve springs can make big differences in row-flow. To start out, a user may consider increasing the **TOLERANCE** up to 50% until these issues are resolved. Here are some other adjustments that can be made:

1. Decrease the length of time that full-page alarms display by changing the **AUTO HIDE ALARMS** setting.
2. Increase the time before a row alarms by increasing the **ALARM TIME** setting.
3. Is Sentinel alarming when the implement is up or when turning around?
 - A. Use the **IntelliSection** option
 - B. Consider disabling alarms with the use of a lift switch
4. Go to the **ROW DETAILS** and disable the problematic row
5. Disable all alarms by checking the **DISABLE ALARMS** box

As-applied rate doesn't match my rate controller

1. Do you have a small implement?
 - A. If your implement has few rows, **AUTO RATE** may not calculate correctly. Try using **MANUAL RATE**
2. Use the FLOW ADJUSTMENT input box on the Rate Setup screen to adjust the Sentinel flowmeters.


NOTE: Don't calibrate the Sentinel to a system that hasn't been calibrated first. Always verify flow and main flowmeter calibration by performing a catch test.

Sentinel Doesn't display speed

1. Change the speed source. Toggle through the speed sources until speed displays.
2. If none of the speed sources are working, a communication problem with the tractor may exist. Consult your tractor dealer or add a GPS speed receiver found in the Accessories section of this manual.

Sentinel Rate Control Troubleshooting

Section Test or Manual Section Valve Operation and Manual Pump Operation




To operate the Section Valves manually, press **Manual Section**, then press any section button to turn the valve off/on.

To test the valves sitting still, put **DUTY CYCLE** to **MAN**, **MASTER** : ON, **SPEED** entered, **Section Control: MAN**.

To run the pump while doing this, enter a number for the Duty Cycle %. The Flow (GPM) and Pressure should be steady. Adjust DC%.

AUTO Test Operation



1. Enter a **SPEED** (tap the box and enter).
2. Select a **RATE**.
3. **Master ON**. Section Control - MAN.
4. Adjust SPEED and RATE to test range.
5. Observe Flow (GPM), Pressure, and Duty Cycle %. On hydraulic pump observe RPM.
6. When testing with water, the pressure will be much less than it will be with a heavier fertilizer. You may have to increase the rate significantly to open all the check valves so all rows will flow.
7. You can go to Manual Section (on the top row) and close some sections to see system response.
8. If Duty Cycle / Rate / Flow oscillate and won't lock in, decrease the Control Speed on the Setup Tab (adjust electric pump by 500, hydraulic by 50). Adjust Control Speed as needed for best field performance.

System Won't Run

1. Is MASTER ON? Is the Product ON? Is there a SPEED? Is there a RATE? Switch Section Control from AUTO to MANUAL. Is there a Duty Cycle %? Is hydraulic flow ON and plumbed correctly?
2. On **Hardware** screen, uncheck TASK CONTROL. If you have TASK CONTROL checked on the Sentinel, Task Control must be activated and turned ON in the display software.
3. Verify settings for Master Switch and Implement Switch. If these boxes are checked, these items must be plugged into the Sentinel harnessing, not into harnessing for another control module. If using an IMPLEMENT SWITCH for Sentinel, is the orientation correct (check arrow on MASTER ON button)?
4. If there is a DC% showing, but the pump is not running, check the hydraulics or the EPD on an electric pump system (check the EPD lights). Verify there is voltage on the 2-pin PWM Connector.

Sentinel Care and Maintenance



Cleaning

Under no circumstance should the Sentinel modules or ECU be cleaned with a pressure washer. While the flow modules and ECU are sealed, the intense pressure generated by pressure washers may penetrate the seals and cause irreversible damage.



It is good to occasionally clean the Sentinel flowmeter tubes. Take off the top fitting and run a Q-tip or soft cloth or brush through the tube on the Sentinel flowmeter. A film can build up over the electrodes inside the tube.

Winterization

SurePoint recommends flushing your system with adequate amounts of water first. Next, use RV antifreeze to winterize your system by pumping an adequate amount through all components. At the beginning of the next season, begin with water to verify the system is in working order with no leaks.



Pre-season Service

(A little time spent here may prevent some downtime when you want to be rolling.)

1. Visually check entire system (hoses, fittings, harnesses, etc.) for any signs of wear or trouble.
2. On the display, recheck all setup screens (see Section D) to verify correct setup.
3. Fill system with water and run in Manual mode to verify components and system are in working order.
4. **Tighten all clamps.** Loose clamps may be evident by leaks on the output side of the system. Loose clamps from the tank to the pump are not always apparent, but can be sources of air getting into the system which can create issues. Hydraulic pumps have tremendous suction and if there is a loose clamp between the pump and the tank, it will suck in air, which will cause erratic flowmeter readings.
5. Push in tubes at all Quick-Connect fittings so they are seated tightly. Tubes that are not fully seated are not always obvious and may not leak, but may allow air in, which can cause check valves to leak.
6. Be sure all rows are flowing and that all metering tubes/orifices are open. (Note: It will take a higher flow rate with water to create enough pressure to open all the check valves.)
7. Run a flow check (Nozzle Test) to verify that system will lock on to a Target Rate. Pressure will be much lower when testing with water than it will be with fertilizer. In some regions, tap water may not be conductive enough for the Sentinel to read accurately. Adding a small amount of fertilizer to the water will generally help.
8. Do a catch test to confirm flowmeter calibration. For best results, do a catch test with the product to be used. There may be a slight difference between the flow cal for water and the flow cal for the product. Always verify flowmeter calibration by comparing acres worked and gallons applied in the field.

Sentinel Accessories


Mounting Brackets



Sentinel Mounting Brackets

Part Number	Description
515-100950	Sentinel ECU Mounting Bracket Kit
515-100201	4-Row Sentinel Mounting Bracket Kit
515-100202	8-Row Sentinel Mounting Bracket Kit
515-100203	12-Row Sentinel Mounting Bracket Kit
515-200201	4-Row Low-Profile Bracket Kit
515-200202	8-Row Low-Profile Bracket Kit
515-200203	12-Row Low-Profile Bracket Kit
515-100701	4-Row Dual Product Add-on Kit
515-100702	8-Row Dual Product Add-on Kit
515-100703	12-Row Dual Product Add-on Kit

ISO Extension Harnesses



Part Number	Description
214-00-3553Y1	10 FT. Front ISO Extension Harness
214-00-3554Y1	20 FT. Front ISO Extension Harness
214-00-3555Y1	30 FT. Front ISO Extension Harness
214-00-3556Y1	40 FT. Front ISO Extension Harness
214-00-3557Y1	50 FT. Front ISO Extension Harness

Implement Height Switches



Part Number	Description
501-100530	Magnetic Finger Type Height Switch
501-1005	Magnetic Mercury Switch
501-100520 / 100525	Push Button Switch for Parallel Arms

GPS Speed Receiver



Part Number	Description
203-01-01410	Astro II with 3-pin MP 150 Shroud

Notes:

Lined area for notes, featuring horizontal ruling lines and a large, faint, diagonal watermark reading "SurePoint Ag Systems".



SurePoint Ag Systems
9904 Hwy 25
Atwood, KS 67730

<https://support.SurePointAg.com>

©2016-2022 SurePoint Ag Systems

