



396-5691Y1

SurePoint M220 SS Mixing Chamber Kit Instructions

Kit Number: 520-00-105075


M220 SS Mixing Chamber Kit - 3/4" HB Inlet/Outlet, 3/8" QC Injection

Kit Number: 520-00-105100

M220 SS Mixing Chamber Kit - 1" HB Inlet/Outlet, 3/8" QC Injection

Kit Number: 520-00-105150

M220 SS Mixing Chamber Kit - 1-1/2" HB Inlet/Outlet, 3/8" QC Injection




Kit Number: 520-00-105200

M220 SS Mixing Chamber Kit - 1" HB Inlet/Outlet, 1" HB Injection

Kit Number: 520-00-105250

M220 SS Mixing Chamber Kit - 1-1/2" HB Inlet/Outlet, 1" HB Injection






Parts List


For 3/8" QC Injection Kits

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	105-100075BRB	1" Manifold x 3/4" HB	2
2	105-100G-H	1" EPDM Manifold Gasket	2
3	105-200G-H	(FOR FC220s) 2" EPDM Manifold Gasket for 220 Series Manifold Fittings	2
4	105-220100CPG	2" Full Port Manifold x 1" Manifold - Reducer Coupling	2
5	105-FC100	1" Manifold Clamp	2
6	105-FC220	2" Full Port Manifold Clamp	2
7	113-06-038050-P	QC to MPT - 3/8" QC x 1/2" MPT - polypropylene	1
8	350-1208	SS Hose Clamp - Size 12 - 1-1/4" Diameter (fits 3/4" AG200)	2
9	507-5610Y1	SurePoint SS Mixing Chamber - M220 Flanges, 1/2" Injection Port	1
10	716-333-0011-102	1/2" SS N-Serve Checkvalve - 12 PSI w/ Extreme Viton	1


Hose Barb, gaskets, and clamps will vary with each kit.



Kit shown: 520-00-105075



Kit shown: 520-00-105100



Kit shown: 520-00-105150



Step by Step Instructions

1. Assemble Mixing Chamber fittings as shown.
2. Connect hose coming from each pump (after the flowmeter) to inlet hose barbs or quick connect fittings.
3. Connect hose from system (Section Valves, LiquiShift, Flow Indicators, etc.) to outlet hose barb.

