




396-2824Y1

Great Plains NutriPro Torpedo Mounting Brackets

Applicator Manufacturer:




Kit Number: 516-04-150150





Parts List and Exploded View

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	462-2821Y1	NutriPro Torpedo Mounting Bracket	2
2	380-1027	1/2" x 6" x 7.5" Square Bend U-Bolt	2
3	323-08	1/2" Flange Nut	4
4	300-080104-5	1/2" x 1-1/4" Hex Head Bolt	4






Step by Step Instructions

1. Using a 1/2" x 6" x 7-1/2" U-bolt, loosely attach 420-2821Y1 to 6x6 center implement frame.
2. Repeat Step 1 for second 420-2821Y1 bracket.

NOTE: In some installations a 1/2" x 4" x 7-1/2" u-bolt may be substituted for the 1/2" x 6" x 7-1/2" u-bolt in order to attach to 4x6 implement frame.



3. Position SurePoint Ag Torpedo bracket (PN 2719Y1, Not Included in Kit 516-04-150150) on 2821Y1 brackets. Bolt loosely using 1/2" hex head bolts and 1/2" flange nuts.
4. Inspect bracket and Torpedo mounting for interference and tighten all bolts.

Note: In order to easily access Torpedo fittings, the preferred orientation is rotated 180° from the picture on the right.

