

396-100015

TT-006



Installation Instructions:

1. Remove depth gauge wheels and disc openers, making sure to note correct shim placement
2. Remove stock seed tube guard
3. Install new Totally Tubular part #006
4. Bend centering tab against row shank
5. Tap centering tab with mallet to firmly hold tube centered
6. Re-install disc openers, making sure you have correct shim placement